

Thermocouple RTD CALIBRATOR

TC 12+



Sonepar India Pvt. Ltd.

B/30, GIDC Electronics Estate,

Sector-25, Gandhinagar-382016, Gujarat, India

☎ +91 79 23287275-77

Email: support.masibus@soneparindia.com

Web: www.masibus.com

1. Introduction	4
Foreword.....	4
Notice	4
Trademarks.....	4
Safety	4
General warnings	5
Electrical warnings.....	5
Cautions.....	5
Summary of functions.....	6
2. TC 12+ Hardware Parts & Accessories.....	7
2.1 Unpacking & Inspection.....	7
2.2 Operational Sections and Connections	8
2.2.1 The Terminal Connections	8
2.2.2 The KeyPad	13
2.2.3 The Display	15
2.2.4 The USB Connection.....	15
2.2.5 Stand for Table Top Use	15
2.3 Power Options	16
2.4 Battery	16
2.4.1 Charge time.....	16
2.4.2 Operating Time	17
3. Start Up & Basic Operations	18
3.1 Power ON or OFF.....	18
3.2 The User Interface	18
3.2.1 The Status Bar	19
3.2.2 The Function key Bar	20
3.2.3 Display Mode	20
3.2.4 Display Operations	24
3.2.5 SCR1 and SCR2 Key Option : mQUICK-SETUP Key	29
4. Menu Layout.....	30
4.1 MENU page	30

4.2 MEASURE Page	30
4.3 SOURCE Page	32
4.3.1 TC Setup	32
4.3.2 RTD Setup	36
4.3.3 Step and Ramp Functionality	41
4.4 DISPLAY Page	44
4.4.1 EM Display Settings	45
4.4.2 Switch test Display Settings	46
4.4.3 TC Display Settings.....	47
4.4.5 RTD Display Settings	49
4.5 DATA LOGGING Page	51
4.5.1 Transferring the Results to a Personal Computer:.....	53
4.6 CJC SETTING Page	54
4.7 Wire Select Page	55
4.8 Alarm Page.....	56
4.9 SETTING Page	57
4.9.1 HART Settings	57
4.9.2 Display Settings	58
4.9.3 Date/Time Settings.....	58
4.9.4 Calibration	59
4.9.5 Battery Info.....	70
4.9.6 Set Password	70
4.9.7 Factory Reset.....	70
4.9.8 About Us	70
5. Maintenance & Troubleshooting.....	71
5.1 Common Problems.....	71
5.2 Replacing the Battery.....	72
5.3 Related Information	72
5.3.1 Thermocouple Measurement/Simulation, Connections and troubleshooting.	73
5.3.2 Parallel Functions in TC 12+	76
6. General Specifications.....	77
6.1 General Specifications	77
6.2 Display & Keys	77

6.3 Special Features	78
6.4 Power Supply.....	78
6.5 Physical.....	78
6.6 Electrical Measurement Parameters and Accuracy	78
6.7 Resistance Measurement 0 ... 4000 ohm	79
6.8 Resistance Simulation 0 ... 4000 ohm	79
6.9 RTD Measurement and Simulation.....	79
6.10 Available RTD Types	80
6.11 Thermocouple/mV Resolution and Accuracy	80
6.12 Enclosure Dimensions	81
6.13 Ordering Code	81
7. Disposal	82

1. Introduction

Foreword

Thanks for purchasing ***Thermocouple RTD Calibrator***. The TC 12+ calibrator is compact hand-held calibrator with an easy to use graphical user interface. This manual describes the basic functions and operation methods. Please read through this user's manual carefully before using the product.

Notice

The contents of this manual are subject to change without notice as a result of continuous improvements to the instrument's performance and functions. Every effort has been made to ensure accuracy in the preparation of this manual. Should any errors or omissions come to your attention, however, please inform our Sales office or sales representative. Under no circumstances may the contents of this manual, in part or in whole, be transcribed or copied without our permission.

Trademarks

Our product names or brand names mentioned in this manual are the trademarks or registered trademarks of **masibus**.

Adobe, Acrobat, and Postscript are either registered trademarks or trademarks of Adobe Systems Incorporated. All other product names mentioned in this user's manual are trademarks or registered trademarks of their respective companies.

Safety

Before you use the instrument, make sure that you read and understand all the related data. This includes: the applicable local safety procedures, this publication, And the instructions for the accessories/options/equipment you are using it with.

Cleaning

For Cleaning Use Soft cloth without water

General warnings

WARNING

It is dangerous to ignore the specified limits for the instrument or its related accessories. Do not use the instrument or accessory if it is not in its normal condition.

Use the applicable protection and obey all safety precautions.

Do not use the instrument in locations with explosive gas, vapor or dust. There is a risk of an explosion

Electrical warnings

To prevent electrical shocks or damage to the instrument, do not connect more than 30V between the terminals, or between the terminals and the ground.

This instrument uses a Lithium-Ion battery pack. To prevent an explosion or fire, do not short circuit, do not disassemble, and keep it safe from damage. For operating conditions, see section 6.1 on Page-85

To prevent battery leakage or heat generation, only use the battery charger in the temperature range 0 to 45°C (32 to 113°F). For operating conditions, see section 6.1 on Page-85.

To make sure the display shows the correct data, disconnect the test leads before you set the power to on or change to another measure or source function.

Cautions

To prevent damage to the display, do not use sharp objects on the screen.

Before you start an operation or procedure in this publication, make sure that you have the necessary skills (if necessary, with qualifications from an approved training establishment). Follow good engineering practice at all times.



When replacing battery replace with the same type of battery (3.7V /3000Ah) from the Manufacturer ONLY. The connector for battery connection is polarized. Please correctly connect or disconnect the connector to the charger board. In case there is battery leakage, Replace as per above instruction.

Summary of functions

This table gives a summary of the available functions with the TC 12+ calibrator.

Function
Easy to read liquid crystal display (LCD) in color
Rechargeable lithium Ion battery with enhanced power control for prolonged battery life.
* Measure RTD(Pt10, Pt50, Pt100, Pt200, Pt400, Pt1000, Pt100(3926),Ni100(672), Ni100(618), Ni120(672), Cu10(427), Cu50(427), Cu100(427)), Resistance (0 to 4000 ohms), mA, mA(2W), Thermocouple (E,J,K,T,B,R,S,N), mV(-10 to 250mV),Switch-test
* Simulate RTD(Pt10, Pt50, Pt100, Pt200, Pt400, Pt1000, Pt100(3926),Ni100(672), Ni100(618), Ni120(672), Cu10(427), Cu50(427), Cu100(427)), Resistance (0 to 4000 ohms),Thermocouple (E,J,K,T,B,R,S,N), mV(-10 to 250mV)
Step/Ramp functions: Automatic/Manual
Universal Serial Bus (USB) communications ports: For computer Communications, Battery Charging& Firmware Upgrade
Data Logging
Other functions: Maximum / Minimum / Average, filter, tare, adjustable backlight, alarm indication (on the display and buzzer), Glance Screen. Continuity Test, Automatic / Manual Wire Selection for RTD Measurement, RTD CJ Compensation.

** Refer to the Specification Sheet on Page: 78*

2. TC 12+ Hardware Parts & Accessories

2.1 Unpacking & Inspection

At the factory each new TC 12+ passes a careful inspection. It should be free of scrapes and scratches and in proper operation order upon receipt. The receiver should, however, inspect the unit for any damage that may have occurred during transit. If there are signs of obvious mechanical damage, package contents are incomplete, or the instrument does not operate according to specifications, contact the purchasing sales office as soon as possible. The standard accessories are as follows:

Sr. No	Description	Qty
1.	Calibration Certificate	1
2.	TC 12+ user guide	1
3.	2mm to 2mm banana cable Red , 100cm	3
4.	2mm to 2mm banana cable Black , 100cm	3
5.	Crocodile clip Red	3
6.	Crocodile clip Black	3
7.	Connecting plug 4mm to 2mm, Red	3
8.	Connecting plug 4mm to 2mm, Black	3
9.	1 Test lead Cu-Cu(Miniature TC Plug Cu type to 4mm Test lead)	1
10.	USB A to mini USB B type cable for PC communication and charging	1
11.	5V 1A charging adaptor	1
12.	Leather cover of TC 12+	1
13.	TC 12+ configuration & Logging software CD-mCAL.	1

If you have to return the instrument to the factory for any reason, use the original packing whenever possible. Include a detailed description of the reason for the return.

2.2 Operational Sections and Connections


All sections and connections are presented in detail on the next pages.

Note:


Keep in mind that the next picture (as well as all pictures of TC 12+ in this manual) has an example configuration of modules. The configuration of your TC 12+ may vary significantly from the one in the picture.



1	Terminal Connection For Measure & Source
2	Keypad Section
3	TFT Color Display
4	USB Connection Slot for PC Communication & Charging



2.2.1 The Terminal Connections



➤ EM (Electric Measurements and 24V Supply) Measure Terminals

Input Terminals for measuring voltage, current, supplying loop power refer specification sheet on **page no. 78 Section 6.6** and **page no. Error! Bookmark not defined. Section 6.13, 6.14.**


• Current Measurement

TC 12+ supports current measurement using either TC 12+ as the loop power supply while at the same time measuring the current or simply measuring the current while an external power supply is used.

The following picture displays the connection for Current Measurement for different mode. And also different ways of providing the supply power to the loop.


➤ mA Current Measurement

In this mode TC 12+ not providing any supply voltage. For proper measurement the external device should capable of providing the voltage supply. If the external device should not capable, an external Power Supply should be connected in series.




➤ mA Read Power Current Measurement

In this mode TC 12+ works as Loop Power Supply while at the same time measuring the current.



• Voltage Measurement

TC 12+ is capable of voltage measurement. The following picture displays the connection for voltage measurement.




➤ RTD Terminals

Terminals for measuring & simulating RTD / Ω . For RTD/ Ω types refer specification sheet on **Page No.78-** Error! Bookmark not defined.

Section 6.8, 6.9, 6.10, 6.11

• RTD/Resistance Source

TC 12+ is capable of RTD/Resistance generation. The following picture displays the connection for RTD and Resistance simulation. In RTD simulation TC 12+ mimics an RTD. The instrument under test generates the current for the RTD measurement. TC 12+ controls the voltage across its terminals so that the resistance (voltage to Current ratio) corresponds to the simulated temperature. Use of 2, 3 or 4-wire connection is up to the receiver instrument. Use only the two leftmost terminals with every wiring option. Connect the possible third and fourth wire according to the Requirements of the connected instrument but use only the two leftmost terminals.




- **RTD / Resistance measurement**

TC 12+ is capable of RTD/Resistance measurement. The following picture displays the connection for RTD and Resistance measurement.


- **2-Wire RTD Measurement**

Two leftmost terminals are used in 2-wire systems. TC 12+ displays the selected wiring system in run page. TC 12+ sources current through the resistor and measure the voltage drop across same terminals. The result is acceptable, if the resistance of the connection wires is significantly smaller than actual measured resistance.




- **3-Wire RTD Measurement**

TC 12+ sources current through the resistor and measure the voltage drop across the entire current loop and across the upper side connection wire as shown in figure. If both left side connection wires are identical, TC 12+ can compensate for the resistance of the connection wires.



➤ 4-Wire RTD Measurement

TC 12+ sources current through the resistor from two left side terminals and measure the voltage drop across the resistor from the two right side terminals. The 4-wire method gives the resistance between the terminals of the resistor; it is insensitive to the resistance of the connection wires.




➤ TC Terminals


Terminal for measuring & simulating thermocouples and mV. This terminal accepts a miniature polarized thermocouple plug with flat, in-line blades spaced 7.9 mm (0.312 in) center to center.

For specification refer **Section 6.12**

TC 12+ supports measurement and simulation of Thermocouple and mV.



2.2.2 The KeyPad




TC 12+ has nine different keys. The key description is given below.

	This key has different functionalities in different menu. And that is shown on Bottom Left Part of Display.
	This key has different functionalities in different menu. And that is shown on Bottom Right Part of Display.
	This key is use to scroll down to the next parameter. And also for decrementing the value of digit in Editbox.
	This key is use to scroll up to the previous parameter. And also for incrementing the value of digit in Editbox.
	This Key is use for Entering into the MENU Page from Run Page. And Also for Saving Edited Parameter to the memory.
	This key is use to log current reading in memory if device is on Run Page& Log Mode is Manual. (In other Page than Run Mode, this key is use to come directly to Run Page. Long presses (Approx.2 Sec) on this key will ON-OFF the Unit.
	This key is used to go in Screen 1 setup menu page.
	This key is used to go in Screen 2 setup menu page.




This key is used to switch between measure and source mode
(Only applicable for T/C,mV and RTD Measure / Simulation).

2.2.3 The Display



OR




- This is a LCD with a 2.4” color display.
- The display has resolution of 240x320 pixels supporting 262K Colors.
- Refer Section 3.2.3 on Page-23 for more details on Different Display Mode and Icon Details

2.2.4 The USB Connection

- The USB Connection Connector is given at Top of the TC 12+. It's a USB A Male to USB mini B Male Connector.
- It is common for PC Communication & Charging the device.
- The USB cable given with the device is USB A-type Male to USB mini B-type male.

2.2.5 Stand for Table Top Use

- This Stand would offer the best support for table top use which gives good viewing angle when TC 12+ is placed table top
- Procedure to Open Stand
 -  is being engraved on the top of the stand. You should pull a bit first.
 -  is being engraved on the bottom of the stand. Now during first pull of above you can release this lower part easily so that you can maneuver the stand as you like.



2.3 Power Options

There are three power options:

- **Lithium-Ion battery:** All the instrument functions are available with a charged battery.
- **5 V DC Charging Adaptor:** It supplies power to the instrument and charges the battery at the same time. It charges the battery when the instrument is on or off.
- **USB mini Type B connection:** This charges the battery when the instrument is off and increases the battery life when the instrument is on. Instrument cannot be charged with USB when it is ON.

2.4 Battery



The Device uses 2000mAh Lithium-Ion Battery. **Explosion or fire, do not short circuit, do not disassemble, and keep it safe from damage. For more specification refer Section 6.4**

- To prevent an explosion or fire, use only our specified battery, battery charger & USB Cable.
- To prevent battery leakage or heat generation, only use the battery charger in the temperature range 0 to 45°C (32 to 113°F).
- To get more information on Battery go to Battery Info Page in Setting Menu.

2.4.1 Charge time

Note:

USB mini

Charge Method	Charge Time (to Full Capacity)
External Charging Adaptor	≈ 5 hours

Type

B connector charges the battery when the instrument is off and increases the battery life when the instrument is on

2.4.2 Operating Time

These are typical operating times for a new, fully charged Li-Ion battery pack with these settings:

- Backlight Intensity set to 5% (Default: 100%)
- Glance Screen Timeout set to 0 to 9999 sec.

Operation	Battery Duration
Continuous operation (measure or source)	> 17hours
Continuous operation (12mA(24V) measure)	>9 hours

Power save options: To get the best battery duration, set a low value for the Backlight Intensity (40%) and a short Timeout.

The maximum operating time without recharging varies depending on the usage and brightness setting of the display light. Also the generated output and the usage of the 24V transmitter supply affect the maximum operating time.

Notes:

- *TC 12+'s memory and the internal clock/calendar use a small amount of power although the calibrator is switched off. Remember to check the capacity of the batteries from time to time although TC 12+ is not in use.*
- *Do not leave TC 12+ without a Battery Pack or an Empty Battery for a long time. TC 12+ may lose its settings if it is left without a support voltage for an extended period.*

3. Start Up & Basic Operations

3.1 Power ON or OFF

To set the instrument power ON, press and release  button until the display comes on. During the power on sequence, the instrument shows a Startup Message and then shows the applicable data.

To set the instrument power off, press and hold (≈ 2 seconds)  button again. When the power is off, the last set of configuration options stays in memory.

3.2 The User Interface

Every time TC 12+ is switched on, the startup message ends in RUN Page.


There are 5 Display Mode available in RUN Page.

1. RTD (Measure/Source) + EM Measure Mode / Switch Test Mode
2. TC (Measure/Source) + EM Measure Mode / Switch Test Mode

This Display Mode can be selected from MENU→DISPLAY Page.

Display Screen is divided into two parts. Which Information to be shows can be selectable in Display Mode Menu Refer Section 3.2.3 on Page-22 for more info.

3.2.1 The Status Bar



The Status Bar at the top of the display is visible only in RUN Page. It is divided into five main sections.

1	Time in HH:MM:SS Format Available in Two Format 24 Hour (default) 12 Hour <i>This setting is available in Date/Time in Settings Menu</i>																
2	Error Code Indicator This Icon is visible if any On-Board Peripherals like RTC, ADC, DAC, etc. not working Properly. Refer Section 5.1 on Page for Troubleshooting these Errors. The List of Error Code available in this device is given below. <table border="1"> <thead> <tr> <th>Error Code</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Memory Corrupted or Device Unable to Read/Write it.</td></tr> <tr> <td>1</td><td>RTC Not working Properly</td></tr> <tr> <td>2</td><td>Device unable to Read battery Information.</td></tr> <tr> <td>3</td><td>Measure Mode Not Working</td></tr> <tr> <td>5</td><td>Data Log Memory Corrupt</td></tr> <tr> <td>6</td><td>Source Mode Not Working</td></tr> <tr> <td>9</td><td>More than one Errors from above list is occurring.</td></tr> </tbody> </table>	Error Code	Description	0	Memory Corrupted or Device Unable to Read/Write it.	1	RTC Not working Properly	2	Device unable to Read battery Information.	3	Measure Mode Not Working	5	Data Log Memory Corrupt	6	Source Mode Not Working	9	More than one Errors from above list is occurring.
Error Code	Description																
0	Memory Corrupted or Device Unable to Read/Write it.																
1	RTC Not working Properly																
2	Device unable to Read battery Information.																
3	Measure Mode Not Working																
5	Data Log Memory Corrupt																
6	Source Mode Not Working																
9	More than one Errors from above list is occurring.																
3	USB Connection Status Icon Icon is visible if USB Charger Adaptor or USB Data Cable is connected to the Device. Icon is different for both indication & this stated below. <table border="1"> <tbody> <tr> <td></td><td>USB Data Cable is connected & Communication with PC is available.</td></tr> <tr> <td></td><td>USB Charger Adaptor is connected. Battery starts Charging.</td></tr> </tbody> </table>		USB Data Cable is connected & Communication with PC is available.		USB Charger Adaptor is connected. Battery starts Charging.												
	USB Data Cable is connected & Communication with PC is available.																
	USB Charger Adaptor is connected. Battery starts Charging.																
4	Battery Charge Percentage Indicator. Always visible in Run page. Battery % is shown in the center of the icon. And the icon background is filled with Green, Yellow & Red color if Battery % is $\geq 50\%$, $\geq 20\%$ & $< 20\%$ respectively.																
5	Data Logging Enable Status Indicator. Icon is visible if Data Logging is enabled and also it will blink when a Datalog is stored to memory.																


3.2.2 The Function key Bar



The Function Key Bar at the bottom of the display is visible all the time. There are 2 Function Key Available. The meaning of the Function Keys varies depending on the situation. A Blank Function key text means that the function is disabled at the moment.

3.2.3 Display Mode

i. RTD (Measure/Source) + EM Measure Mode / Switch Test Mode




Display Mode				
RTD Mode	Shows the Current RTD Mode			
	<table border="1"> <tr> <td>←</td><td>RTD Measure Mode</td></tr> <tr> <td>→</td><td>RTD Source Mode</td></tr> </table>	←	RTD Measure Mode	→
←	RTD Measure Mode			
→	RTD Source Mode			
RTD Type	Shows the current RTD Type.			
Wire Selection	Wire connection for RTD and Resistance Measurement / Source			

	<table><tr><td>2W</td><td>2 wire connection</td></tr><tr><td>3W</td><td>3 wire connection</td></tr><tr><td>4W</td><td>4 wire connection</td></tr></table>	2W	2 wire connection	3W	3 wire connection	4W	4 wire connection										
2W	2 wire connection																
3W	3 wire connection																
4W	4 wire connection																
Reading	Shows the RTD reading according to RTD Type.																
STEP/RAMP Icon	Shows the Icon indicating STEP/RAMP mode. Only applicable if RTDmode is <i>SOURCE</i>. <table><tr><td></td><td>Manual Step</td><td></td><td>Rising Ramp</td></tr><tr><td></td><td>Step UP</td><td></td><td>Falling Ramp</td></tr><tr><td></td><td>Step DOWN</td><td></td><td>Ramp Hold @ 0%</td></tr><tr><td></td><td></td><td></td><td>Ramp Hold @ 100%</td></tr></table>		Manual Step		Rising Ramp		Step UP		Falling Ramp		Step DOWN		Ramp Hold @ 0%				Ramp Hold @ 100%
	Manual Step		Rising Ramp														
	Step UP		Falling Ramp														
	Step DOWN		Ramp Hold @ 0%														
			Ramp Hold @ 100%														
Additional Info.	Shows the Addition Information according to RTD Mode & Additional Info selected in <i>MENU → DISPLAY→RTD terminal</i> .																
Bar Graph	Horizontal Bar graph according to RTD Percentage Value (0.00% - 100.00%). The value scales according to RTD reading and Input 0% & 100% value as set in <i>MENU → DISPLAY→RTD terminal</i> Menu.																
Percentage Value	The Percentage Value in according to RTD Reading.																
Wire Select	Shows which RTD configuration is used. (2-wire, 3-wire, 4-wire)																
Source Display Mode	Shows which display mode is selected either percentage or actual.																
Actual Value	When display mode percentage Actual value bar display the actual source value.																
I (EX)	When RTD is in source mode it shows the excitation current which comes from the measure device.																

Measure Window					
Switch Status	Switch Status Icon <table border="1"> <tr> <td></td><td>Switch OPEN (OFF)</td></tr> <tr> <td></td><td>Switch CLOSE (ON)</td></tr> </table>		Switch OPEN (OFF)		Switch CLOSE (ON)
	Switch OPEN (OFF)				
	Switch CLOSE (ON)				
Switch OPEN	Displays the Source Reading value after the switch OPEN was detected.				
Switch CLOSE	Displays the Source Reading value after the switch CLOSE was detected.				

ii. TC (Measure/Source) + EM Measure Mode / Switch Test Mode



Display Mode		
Input Type	The Input Type.	
Display Mode	Actual	Displays the Raw Input Value without any scaling
	Percentage	Displays the Percentage Value.
Reading	The Reading as per the Measure Display Mode	
Bar Graph	Horizontal Bar graph according to Input Percentage Value (0.00% - 100.00%).	
Percentage Value	The Percentage Value in Percentage according to Input Value.	
Tare	The Tare Value Set from <i>MENU→DISPLAY→EM Terminal-Tare</i> page	
Actual Value	The Raw Input Value without any scaling This will appear only if Main Display in <i>MENU→DISPLAY→EM Terminal</i> is set to PERCENTAGE/SCALED .	
Min	Displays the minimum value found after a measurement was started or minimum was reset.	
Max	Displays the maximum value found after a measurement was started or maximum was reset.	
Max-Min	Displays the Maximum-Minimum value found after a measurement was started or Maximum-Minimum was reset.	
Cumulative Average	Displays the Cumulative Average value found after a measurement was started or Cumulative Average was reset.	

Measure Window		
Input Type	The Input Type.	
	mA	mA Current Input
	mA(24V)	mA Current (Read Power-24V) Input
	V	V Voltage Input
Measure Display Mode	The Measure Reading Display Mode.	
	Actual	Displays the Raw Input Value without any scaling
	Percentage	Displays the Percentage Value in (0.00% - 100.00%)
	Scaled	Displays the Scaled Value
Measure Reading	The Reading as per the Measure Display Mode	
Measure Info 1	Shows the One of the available Addition Information. This can be selected by Additional Info. 1 List in <i>MENU → DISPLAY → MEASURE</i> page.	
Measure Info 2	Shows the One of the available Addition Information. This can be selected by Additional Info. 2 List in <i>MENU → DISPLAY → MEASURE</i> page. This will disable if Bargraph is selected as Additional Info1 in <i>MENU → DISPLAY → MEASURE</i> page.	
HART Icon	HART Enable Status Icon.	

3.2.4 Display Operations

There are mainly four types of widgets available in the Device Menu Style.

- i. ListBox
- ii. EditBox
- iii. CheckBox
- iv. RadioButtonBox


The below section will show how to change the value of different widgets.

- **ListBox**

ListBox are used when there is a limited amount of preset values. You have to select one of the available options. The list of available options is displayed in the Centre part.

A ListBoxList opens when you press the **F1** key. Use **UP/DOWN** key to scroll through the available options. Select one of the options with the **ENTER** key.


Example: How to change of Input Type (I/P Type) from mA to V.
This Option is available in *MENU*→*EM SETUP* Page.



- **EditBox**

Edit Box is used where a large range of value can be possible for a parameter.

To edit the value of an EditBox press **F1** key. After that EditBox enters into the Edit mode where **F1&F2** keys are works as shifter. User can shift to desired digit and using **UP** or **DOWN** key digit value can be increment or decrement. The modified value can be save using **MENU/ENT** key.




The above figure shows the example how to change Input High (100%) Range from 24.000 to 10.000 mA.

There are mainly 2 types of EditBox in this device. In most of the EditBox changing of decimal point & changing of sign is not

allowed. But there are few EditBox, where these are allowed. Examples Scaled Low (0%) & High (100%) etc.

The below figure shown the example how to change decimal point of the Input Scaled High (100%) Range.




To change the sign of the value, shift to the sign digit and pressing UP or DOWN key will toggle the sign.

- **Checkbox**

CheckBox is used where Binary Value (1/0, True/False) is available for any parameter.

To change the CheckBox status press **F1** key. This will enter into the edit mode. In this mode status can be toggled by pressing **F1** key. Press **MENU/ENT** key to store new status.




- **RadioButtonBox**

RadioButtonBox is used where very few values can be possible and all the available values need to be visible.

In this device, two types of RadioButtonBox are available. One with 1 value can be selectable & the other where 1 or 2 values can be selectable at a time.


In RadioButtonBox the other option can be selected by pressing MENU/ENT key on that option. When pressing this key the new option will be selected and the other option will be disabled.

Below an example is given, How to change RTD Source Mode from STEP to RAMP.




3.2.5 SCR1 and SCR2 Key Option : mQUICK-SETUP Key


TC 12+ has divided the RUN Screen into Two Parts: SCR1 and SCR2 as shown in below figure. Both windows can independently be configured to display a measurement value.



i. SCR1 Display



ii. SCR2 Display




4. Menu Layout

4.1 MENU page

There are mainly eight Menus in this device.


To enter into the MENU page press **MENU/ENT** key & press **F2** key to come out from Menu page.



EM SETUP	Contains Parameters related to EM Measure Mode like Input Type, Range etc.
TC/RTD SETUP	Contains Parameters related to RTD like RTD Mode, RTD Type etc.
DISPLAY	Contains Parameters related to different display mode for RUN page
LOGGING	Contains Parameters related to Data Logging.
CJC Setting	Contains Parameters related to CJC setting
Wire Select	Contains Parameters related to wire selection mode
Alarm	Contains Parameters related to Alarm
Setting	Contains Parameters related to General Settings of the device like display, Date/Time, Calibration, Reset, etc.

4.2 MEASURE Page

This Page is appears in *RUN* → *MENU* → *EM SETUP*.




This page contains parameters related to EM Measure like Input Type, Input Range, Scaling and Transfer Function. The Description of the Parameters appear on this page is given below.

Parameter Name	Description / Options
I/P Type (Input Type)	Measure Input Type <u>Available Options:</u> mA : 0.000 to 24.000 mA DC mA(24V) : 0.000 to 24.000 mA DC V : 0.000 to 30.000 V DC
Input Range Low (0%)	Low Range for Measure Input. Only for mA, mA(24V) and V <u>Range:</u> Default Input Low to Input Range High (100%) This parameter is enabled, if Main Display in <i>MENU → DISPLAY → EM SETUP</i> is set to Percentage or Scaled .
Input Range High (100%)	High Range for Measure Input. Only for mA, mA(24V) and V <u>Range:</u> Input Range Low(0%) to Default Input High This parameter is enabled, if Main Display in <i>MENU → DISPLAY → EM SETUP</i> is set to Percentage or Scaled .
Scaled Input Range Low (0%)	Scaling Low Range for Measure Input. Only for mA, mA(24V) and V <u>Range:</u> -99999 to Scaled Input Range High (100%) Decimal Point for this EditBox can be changeable. This parameter is enabled, if Main Display in <i>MENU → DISPLAY → EM SETUP</i> is set to Scaled .
Scaled Input Range High (100%)	Scaling High Range for Measure Input. Only for mA, mA(24V) and V <u>Range:</u> Scaled Input Range Low(0%) to 99999 Decimal Point for this EditBox can be changeable. This parameter is enabled, if Main Display in <i>MENU → DISPLAY → EM SETUP</i> is set to Scaled .
TF (Transfer Function)	Transfer Function for Scaling. Only for mA, mA(24V) and V <u>Available Options:</u> Linear x^2 (x^2) $x^{(1/2)}$ ($\sqrt{x}$) This parameter is enabled, if Main Display in <i>MENU → DISPLAY → EM SETUP</i> is set to Scaled .

4.3 SOURCE Page

4.3.1 TC Setup

This Page is appears in *RUN → MENU → TC SETUP*.




This page contains parameters related to Thermocouple like TC Mode Type, TC Type, Unit, TC Source Mode etc. The Description of the Parameters appear on this page is given below.

Parameter Name	Description / Options																										
TC Mode	Thermocouple Mode <u>Available Options:</u> MEASURE SOURCE																										
TC Select	Select the Thermocouple/mV Type for Measurement / Simulation <u>Available Options:</u> <table><tr><th>TC Type</th><th>Range</th><th>Resolution</th></tr><tr><td>E TC</td><td>-200.0 to 1000.0 °C</td><td rowspan="8">0.1 °C</td></tr><tr><td>J TC</td><td>-200.0 to 1200.0 °C</td></tr><tr><td>K TC</td><td>-200.0 to 1372.0 °C</td></tr><tr><td>T TC</td><td>-200.0 to 400.0 °C</td></tr><tr><td>B TC</td><td>450.0 to 1800.0 °C</td></tr><tr><td>R TC</td><td>0.0 to 1750.0 °C</td></tr><tr><td>S TC</td><td>0.0 to 1750.0 °C</td></tr><tr><td>N TC</td><td>-200.0 to 1300.0 °C</td></tr><tr><td>-10 to 80 mV</td><td>-10.000 to 80.000 mV</td><td>0.001 mV</td></tr><tr><td>-10 to 250 mV</td><td>-10.00 to 250.00 mV</td><td>0.01 mV</td></tr></table> Refer section 6 on page 73 for more details on TC type and its available range.	TC Type	Range	Resolution	E TC	-200.0 to 1000.0 °C	0.1 °C	J TC	-200.0 to 1200.0 °C	K TC	-200.0 to 1372.0 °C	T TC	-200.0 to 400.0 °C	B TC	450.0 to 1800.0 °C	R TC	0.0 to 1750.0 °C	S TC	0.0 to 1750.0 °C	N TC	-200.0 to 1300.0 °C	-10 to 80 mV	-10.000 to 80.000 mV	0.001 mV	-10 to 250 mV	-10.00 to 250.00 mV	0.01 mV
TC Type	Range	Resolution																									
E TC	-200.0 to 1000.0 °C	0.1 °C																									
J TC	-200.0 to 1200.0 °C																										
K TC	-200.0 to 1372.0 °C																										
T TC	-200.0 to 400.0 °C																										
B TC	450.0 to 1800.0 °C																										
R TC	0.0 to 1750.0 °C																										
S TC	0.0 to 1750.0 °C																										
N TC	-200.0 to 1300.0 °C																										
-10 to 80 mV	-10.000 to 80.000 mV	0.001 mV																									
-10 to 250 mV	-10.00 to 250.00 mV	0.01 mV																									
TC Unit Unit	Measure/Source Reading Unit																										

	<u>Available Options:</u> Celsius Fahrenheit Kelvin
Source Mode	TC Source Output Format This option appear only if TC Mode is <i>SOURCE</i> . <u>Available Options:</u> STEP RAMP At a time one can be selectable. Press F1 key on the one of the option for more settings.
Reset Additional Info.	Reset the Additional Information of Measure mode like Minimum & Maximum This option appear only if TC Mode is <i>MEASURE</i> .

• STEP Page:




Parameter Name	Description / Options
Low	Starting Value of Step. Enter value according to TC Display Mode. If display mode is actual enter value in temperature/mV and if display mode is % enter value in %.
High	Ending Value of Step. Enter value according to TC Display Mode. If display mode is actual enter value in temperature/mV and if display mode is % enter value in %.
Manual (Output Type)	Step Manual Mode Selection CheckBox. Ticking this checkbox will enable Step Manual Mode. And Un-ticking will enable Auto Step Mode.
Step Time (s)	Enter the time for a single step in seconds, <u>Range:</u> 1 to 9999 This parameter is enabled only for Auto Step Mode (Manual CheckBox is

	Un-Checked)
Step Definition	Step Definition for the Step function. <u>Available Options:</u> Temperature (Appear only if TC Display mode is Actual) Percentage (Appear only if TC Display mode is Percentage) User Defined
Step	Step Value in Temperature/mV/% according to TC Display Mode and TC unit. Only appear if Step Definition is Temperature or Percentage.
Define Steps	User Defined Step value for Manual and Auto Step Mode. This option appear only if Step Definition is User Defined. Maximum 10 step value can be configured. First enter the no of step and then define step value in serial order.
Repeat Format	How the stepping should be done. <u>Available Options:</u> UP DOWN UP/DOWN DOWN/UP This parameter is enabled only for Auto Step Mode (Manual CheckBox is Un-Checked)
Repeat Repeat Counts	Defines how many times the steps are repeated <u>Range:</u> 1 to 9999 This parameter is enabled only for Auto Step Mode (Manual CheckBox is Un-Checked)

Note:-

For Manual Stepping and Auto Stepping refer ET Setup Section 4.3.1.

- **RAMP Page:**




Parameter Name	Description / Options
Low	Starting Value of Ramp. Enter value according to TC Display Mode. If display mode is actual enter value in temperature/mV and if display mode is % enter value in %.
High	Ending Value of Ramp. Enter value according to TC Display Mode. If display mode is actual enter value in temperature/mV and if display mode is % enter value in %.
Hold@0%(s)	Time to wait at Low (0%) level in second. This parameter is use for Repeat Format UP/DOWN or DOWN/UP . <u>Range:</u> 0 to 9999
Rise Time (s)	Time to Increase from Low to High Level. <u>Range:</u> 1 to 9999
Hold@100%(s)	Time to wait at High (100%) level in second. This parameter is use for Repeat Format UP/DOWN or DOWN/UP . <u>Range:</u> 0 to 9999
Fall Time (s)	Time to decrease from High to Low Level. <u>Range:</u> 1 to 9999
Repeat Format	How the Ramp should be done. <u>Available Options:</u> UP DOWN UP/DOWN DOWN/UP
Repeat Repeat Counts	Defines how many times the steps are repeated <u>Range:</u> 1 to 9999

Note:-

For Starting the RAMP refer Page no 41 of ET Setup Section

4.3.2 RTD Setup


This Page is appears in *RUN → MENU → RTD SETUP*.



This page contains parameters related to RTD like RTD ModeType, RTD select, Unit, RTD Source Mode etc. The Description of the Parameters appear on this page is given below.

Parameter Name	Description / Options
RTD Mode	RTD Mode <u>Available Options:</u> MEASURE SOURCE
RTD Select	Select the RTD Type for Measurement / Simulation Refer section 6 on page 48 for more details on RTD type and its available range.
Unit	Measure/Source Reading Unit <u>Available Options:</u> Celsius Fahrenheit Kelvin
Continuity Test	To test continuity. This Option appear only if RTD Mode is MEASURE.
Reset Additional Info.	Reset the Additional Info Like Min, Max of RTD. This option appears only if RTD Mode is <i>MEASURE</i> .
RTD Source Mode	RTD Source Output Format This option appears only if RTD Mode is <i>SOURCE</i> . <u>Available Options:</u> STEP RAMP At a time one can be selectable. Press F1 key on the one of the option for more settings.

STEP Page:




Parameter Name	Description / Options
Low	Starting Value of Step. Enter value according to RTD Display Mode. If display mode is actual enter value in ohms/°C and if display mode is % enter value in %.
High	Ending Value of Step. Enter value according to RTD Display Mode. If display mode is actual enter value in ohms/°C and if display mode is % enter value in %.
Manual (Output Type)	Step Manual Mode Selection CheckBox. Ticking this checkbox will enable Step Manual Mode. And Un-ticking will enable Auto Step Mode.
Step Time (s)	Enter the time for a single step in seconds, <u>Range:</u> 1 to 9999 This parameter is enabled only for Auto Step Mode (Manual CheckBox is Un-Checked)
Step Definition	Step Definition for the Step function. <u>Available Options:</u> Step Value User Defined
Step	Step Value in Temperature/Ohms/% according to RTD Display Mode and RTD unit. Only appears if Step Definition is Step Value.
Define Steps	User Defined Step value for Manual and Auto Step Mode. This option appear only if Step Definition is User Defined. Maximum 10 step value can be configured. First enter the no of step and then define step value in serial order.
Repeat Format	How the stepping should be done.

	<u>Available Options:</u> UP DOWN UP/DOWN DOWN/UP This parameter is enabled only for Auto Step Mode (Manual CheckBox is Un-Checked)
Repeat Repeat Counts	Defines how many times the steps are repeated <u>Range:</u> 0 to 9999 (0=infinity) This parameter is enabled only for Auto Step Mode (Manual CheckBox is Un-Checked)

Note:-

For Manual Stepping and Auto Stepping refer Page no – 39, 40 of ET Setup Section.


- **RAMP Page :**



Parameter Name	Description / Options
Low	Starting Value of Ramp. Enter value according to RTD Display Mode. If display mode is actual enter value in ohms and if display mode is % enter value in %.
High	Ending Value of Ramp. Enter value according to RTD Display Mode. If display mode is actual enter value in ohms and if display mode is % enter value in %.
Hold@0%(s)	Time to wait at Low (0%) level in second. This parameter is use for Repeat Format UP/DOWN or DOWN/UP . <u>Range:</u> 0 to 9999
Rise Time (s)	Time to Increase from Low to High Level. <u>Range:</u> 1 to 9999
Hold@100%(s)	Time to wait at High (100%) level in second. This parameter is use for Repeat Format UP/DOWN or DOWN/UP . <u>Range:</u> 0 to 9999
Fall Time (s)	Time to decrease from High to Low Level. <u>Range:</u> 1 to 9999
Repeat Format	How the Ramp should be done. <u>Available Options:</u> UP DOWN UP/DOWN DOWN/UP
Repeat Repeat Counts	Defines how many times the steps are repeated <u>Range:</u> 0 to 9999 (0=infinity)


Note:-For Starting the RAMP refer ET Setup Section 4.3.1

• **Continuity Test:**




Parameter Name	Description / Options
Continuity Feature	Continuity Feature Selection Radiobuttonbox. Selecting radiobuttonbox will enable continuity feature for RTD Measure Mode.
Threshold	Enter the threshold value of resistance up to which continuity test is applied. <u>Range:</u> 0 to 100

When Testing Continuity Beep sounds and continuity symbol appear on run page as shown in below figure. When resistance between the Ω Measure terminal is less than 25Ω (or defined in threshold parameter). To test the continuity remove power from the circuit to be tested.



4.3.3 Step and Ramp Functionality

- **STEP Function:**



➤ **Manual Stepping**

To Enable Manual Stepping, select Source Type as STEP & Check the Manual CheckBox.

If this mode is enabled, ▲ ▼ icon will appear in Source Display Window in RUN Page.

Pressing UP or DOWN key in RUN Page will Increment or Decrement Source Value by Step Size specified in STEP Page.

In RUN Page, Source Value can directly change by Pressing **F1** key (EDIT) and modifying value like in EditBox. & STEP Setting can be accessed directly by **F2** key (SETTING).

➤ **Auto Stepping**

To Enable Auto Stepping, select Source Type as STEP & Un-Check the Manual CheckBox.

If this mode is enabled, ⏮ (Step UP) or ⏭ (Step Down) icon will appear in Source Display Window in RUN Page and F1 & F2 Button change to **START&SETTING** respectively.

Automated Step can be started by Pressing **F1** key (START). After that F1 & F2 key will change to **PAUSE&STOP** respectively. So by pressing F1 & F2 key running STEP can be PAUSE or STOP at any time in RUN Page.


STEP Setting can be accessed directly by **F2** key (SETTING).

Note:

While STEP is running STEP settings can't be accessible and Source Page Parameter settings can't be change. Stop STEP before changing any settings

.

- **RAMP Function:**



➤ **Starting the RAMP**

To Enable Ramp, select Source Type as RAMP.

If this mode is enabled, $\nearrow$ (Rising Ramp) or $\searrow$ (Falling Ramp) or $\overline{\nearrow}$ (Ramp Hold @ 100%) or $\overline{\searrow}$ (Ramp Hold @ 0%) icon will appear in Source Display Window according to current RAMP mode in RUN Page and F1 & F2 Button change to **START&SETTING** respectively.


RAMP can be started by Pressing **F1** key (START). After that F1 & F2 key will change to **PAUSE&STOP** respectively. So by pressing F1 & F2 key running RAMP can be PAUSE or STOP at any time in RUN Page.

Note:

While RAMP is running RAMP settings can't be accessible and Source Page Parameter settings can't be change. Stop RAMP before changing any settings.

4.4 DISPLAY Page

This Page is appears in *RUN → MENU → DISPLAY*.




There is mainly six RUN Display Mode possible in this device. And this mode can be selected from the above Page. What information to be shown in each RUN Display Mode can be defined by this page.

In this page there is one **RadioButtonBox**. At a time two option can be selected. The possible combinations are given below.

1	EM + TC
2	EM + RTD
3	Switch Test + TC
4	Switch Test + RTD

4.4.1 EM Display Settings


This Page is appears in *RUN → MENU → DISPLAY → EM Terminal*.



Parameter Name	Description / Options						
Main Display	Select which Reading to be display as a Main Reading (Reading Displays in Box in RUN Page). <u>Available Options:</u> <table border="1"> <tr> <td>Actual</td><td>Display the Actual Input Value</td></tr> <tr> <td>Percentage</td><td>Display the Percentage Value of the Input. The Value depends on Input Range. These settings are available from <i>MENU → EM SETUP</i>.</td></tr> <tr> <td>Scaled</td><td>Display the Scaled Value of the Input. The Scale Value depends on Input Range, Input Scaled Range & Transfer Function. These settings are available from <i>MENU → EM SETUP</i>.</td></tr> </table>	Actual	Display the Actual Input Value	Percentage	Display the Percentage Value of the Input. The Value depends on Input Range. These settings are available from <i>MENU → EM SETUP</i> .	Scaled	Display the Scaled Value of the Input. The Scale Value depends on Input Range, Input Scaled Range & Transfer Function. These settings are available from <i>MENU → EM SETUP</i> .
Actual	Display the Actual Input Value						
Percentage	Display the Percentage Value of the Input. The Value depends on Input Range. These settings are available from <i>MENU → EM SETUP</i> .						
Scaled	Display the Scaled Value of the Input. The Scale Value depends on Input Range, Input Scaled Range & Transfer Function. These settings are available from <i>MENU → EM SETUP</i> .						
Filter(sec)	1st Order IIR Low Pass Filter for Input Reading. Filter is useful when a measurement signal contains unwanted noise. <u>Range:</u> 0.0 to 60.0 sec						
Tare(unit)	The Tare value is subtracted from the reading of the measured value. Here unit is changed according to current Input Type and Measure Display Mode. <u>Range:</u> In accordance with Input Range & Measure Display Mode. Note: Beware of the problems that may result in not seeing the true measurement value.						

4.4.2 Switch test Display Settings


This Page is appears in *RUN → MENU → DISPLAY → SWITCH TEST*.



Parameter Name	Description / Options				
Mode	Switch Test Operation Mode <u>Available Options:</u> <table border="1"> <tr> <td>2V(24Vdc,26mA)</td><td>Switch Close when External Switch (Potential Free Contacts) short & Switch Open is External Switch open.</td></tr> <tr> <td>Voltage Trigger</td><td>Switch Close when Input Voltage > Trigger Voltage Switch Open when Input Voltage < Trigger Voltage</td></tr> </table> All the MEASURE Page parameters are disabled if Switch Test Display Mode is selected.	2V(24Vdc,26mA)	Switch Close when External Switch (Potential Free Contacts) short & Switch Open is External Switch open.	Voltage Trigger	Switch Close when Input Voltage > Trigger Voltage Switch Open when Input Voltage < Trigger Voltage
2V(24Vdc,26mA)	Switch Close when External Switch (Potential Free Contacts) short & Switch Open is External Switch open.				
Voltage Trigger	Switch Close when Input Voltage > Trigger Voltage Switch Open when Input Voltage < Trigger Voltage				
Trigger Voltage	Trigger Voltage value for Voltage Trigger Switch Test Mode. <u>Range:</u> 0 to 30 V Enable only for Switch Test Mode as Voltage Trigger.				
Sound	Sound Setting for Switch Test Mode <u>Available Options:</u> Off When Switch Close When Switch Open				
Reverse Logic	Switch Test Switch Logic Reverse Selection. Switch Open-Close Logic Reverse if this CheckBox is Checked.				

4.4.3 TC Display Settings

This Page is appears in *RUN → MENU → DISPLAY → TC Terminal*.




Parameter Name	Description / Options																					
Main Display	Select which Reading to be display as a Main Reading (Reading Displays in Box in RUN Page).																					
	Available Options:																					
	<table><tr><td>Actual</td><td>Display the Actual Thermocouple/mV Value</td></tr><tr><td>Percentage</td><td>Display the Percentage Value of Thermocouple/mV according to value set in 0% & 100%.</td></tr></table>	Actual	Display the Actual Thermocouple/mV Value	Percentage	Display the Percentage Value of Thermocouple/mV according to value set in 0% & 100%.																	
Actual	Display the Actual Thermocouple/mV Value																					
Percentage	Display the Percentage Value of Thermocouple/mV according to value set in 0% & 100%.																					
0%	Low Value in Temperature/mV for (0-100%) scaling.																					
100%	High Value in Temperature/mV for (0-100%) scaling.																					
Additional Info.1	Choose which information to be shown as TC Mode Additional Information on RUN Page.																					
	Available Options for TC Measure Mode:																					
	<table><tr><th>Options</th><th>Icon</th><th>Description</th></tr><tr><td>None</td><td>-</td><td>No info is visible.</td></tr><tr><td>Actual Value</td><td></td><td>Shows the Actual Thermocouple Temperature/mV value without any scaling. This option is available only if TC Display Mode is Percentage.</td></tr><tr><td>mV</td><td></td><td>Shows the Thermovoltage which is measured through TC terminals.</td></tr><tr><td>mV w/o CJC</td><td></td><td>Shows the Thermovoltage according to TC Temperature with adding CJ Temperature mV.</td></tr><tr><td>Maximum</td><td></td><td>Shows the Maximum measured reading from the time when info last reset.</td></tr><tr><td>Minimum</td><td></td><td>Shows the Minimum measured reading from the time when info last reset.</td></tr></table>	Options	Icon	Description	None	-	No info is visible.	Actual Value		Shows the Actual Thermocouple Temperature/mV value without any scaling. This option is available only if TC Display Mode is Percentage.	mV		Shows the Thermovoltage which is measured through TC terminals.	mV w/o CJC		Shows the Thermovoltage according to TC Temperature with adding CJ Temperature mV.	Maximum		Shows the Maximum measured reading from the time when info last reset.	Minimum		Shows the Minimum measured reading from the time when info last reset.
	Options	Icon	Description																			
	None	-	No info is visible.																			
	Actual Value		Shows the Actual Thermocouple Temperature/mV value without any scaling. This option is available only if TC Display Mode is Percentage.																			
	mV		Shows the Thermovoltage which is measured through TC terminals.																			
	mV w/o CJC		Shows the Thermovoltage according to TC Temperature with adding CJ Temperature mV.																			
Maximum		Shows the Maximum measured reading from the time when info last reset.																				
Minimum		Shows the Minimum measured reading from the time when info last reset.																				

	Min & Max		Shows the Minimum (in place of mV_0) and Maximum value both together. This option available only for only TC Display mode.
	Available Options for TC Source Mode:		
	Options	Icon	Description
	None	-	No info is visible.
	Actual Value		Shows the Actual Thermocouple Temperature/mV value without any scaling. This option is available only if TC Display Mode is Percentage.
	mV		Shows the Thermovoltage according to Temperature including CJ temperature mV. The mV which is sourced through TC Terminal.
	Reading Feedback		Shows the Feedback Temperature/mV Reading. When TC 12+ generate mV, it uses its own measurement function to control the generated value. This feedback measurement is shows if this option is selected.
	%Error		Shows the error in % between the Desired Source Value and Feedback value.
	mV Feedback		Shows the Feedback mV Reading.
	mV w/o CJC		Shows the Thermovoltage according to Temperature (for CJ Temperature = 0 °C)
Filter(sec)	1st Order IIR Low Pass Filter for TC Measure Reading. This option is available only for TC mode is Measure. Filter is useful when a measurement signal contains unwanted noise. <u>Range:</u> 0.0 to 60.0 sec		

4.4.5 RTD Display Settings

This Page is appears in *RUN → MENU → DISPLAY → RTD Terminal*.




Parameter Name	Description / Options																		
Main Display	Select which Reading to be display as a Main Reading (Reading Displays in Box in RUN Page).																		
	<u>Available Options:</u>																		
	<table><tr><td>Actual</td><td>Display the Actual RTD/Resistance Value</td></tr><tr><td>Percentage</td><td>Display the Percentage Value of RTD/Resistance according to value set in 0% & 100%.</td></tr></table>	Actual	Display the Actual RTD/Resistance Value	Percentage	Display the Percentage Value of RTD/Resistance according to value set in 0% & 100%.														
Actual	Display the Actual RTD/Resistance Value																		
Percentage	Display the Percentage Value of RTD/Resistance according to value set in 0% & 100%.																		
0%	Low Value in Temperature/ohms for (0-100%) scaling.																		
100%	High Value in Temperature/ohms for (0-100%) scaling.																		
Additional Info.1	Choose which information to be shown as RTD Mode Additional Information on RUN Page.																		
	<u>Available Options for RTD Measure Mode:</u>																		
	<table><tr><th>Options</th><th>Icon</th><th>Description</th></tr><tr><td>None</td><td>-</td><td>No info is visible.</td></tr><tr><td>Actual Value</td><td></td><td>Shows the Actual RTD Temperature/ohms value without any scaling. This option is available only if RTD Display Mode is Percentage.</td></tr><tr><td>Maximum</td><td></td><td>Shows the Maximum measured reading from the time when info last reset.</td></tr><tr><td>Minimum</td><td></td><td>Shows the Minimum measured reading from the time when info last reset.</td></tr><tr><td>Min & Max</td><td></td><td>Shows the Minimum and Maximum value both together. This option available only for RTDDisplay mode.</td></tr></table>	Options	Icon	Description	None	-	No info is visible.	Actual Value		Shows the Actual RTD Temperature/ohms value without any scaling. This option is available only if RTD Display Mode is Percentage.	Maximum		Shows the Maximum measured reading from the time when info last reset.	Minimum		Shows the Minimum measured reading from the time when info last reset.	Min & Max		Shows the Minimum and Maximum value both together. This option available only for RTDDisplay mode.
	Options	Icon	Description																
	None	-	No info is visible.																
	Actual Value		Shows the Actual RTD Temperature/ohms value without any scaling. This option is available only if RTD Display Mode is Percentage.																
	Maximum		Shows the Maximum measured reading from the time when info last reset.																
Minimum		Shows the Minimum measured reading from the time when info last reset.																	
Min & Max		Shows the Minimum and Maximum value both together. This option available only for RTDDisplay mode.																	

	<u>Available Options for RTD Source Mode:</u>		
	Options	Icon	Description
	None	-	No info is visible.
	Actual Value	AV	Shows the Actual RTD Temperature/ohms value without any scaling. This option is available only if RTD Display Mode is Percentage.
	Excitation Current	I (EX)	Shows the current which is sourced by instrument under test.
Filter(sec)	1st Order IIR Low Pass Filter for RTD Measure Reading. This option is available only for RTD mode is Measure. Filter is useful when a measurement signal contains unwanted noise. <u>Range:</u> 0.0 to 60.0 sec		

4.5 DATA LOGGING Page

This section gives examples of how to log Readings with time and date over a set time period or on a key press. Logged data is stored in a user defined file in internal memory.

This Page is appears in *RUN → MENU → LOGGING*.



Parameter Name	Description / Options						
Trigger	Data Logging Trigger Mode Selection. <u>Available Options:</u> <table border="1"> <tr> <td>Key Press</td><td>Log Data on pressing  from RUN key Page.</td></tr> <tr> <td>Periodic</td><td>Log Data periodically at every Sampling Rate for total time specified by Logging Time.</td></tr> </table>	Key Press	Log Data on pressing  from RUN key Page.	Periodic	Log Data periodically at every Sampling Rate for total time specified by Logging Time.		
Key Press	Log Data on pressing  from RUN key Page.						
Periodic	Log Data periodically at every Sampling Rate for total time specified by Logging Time.						
Mode	Data Mode Selection for Logging <u>Available Options:</u> <table border="1"> <tr> <td>EM</td><td>Log only EM Measure Readings.</td></tr> <tr> <td>RTD</td><td>Log only RTD Terminal Readings.</td></tr> <tr> <td>EM+RTD</td><td>Log EM Measure and RTD Terminal both Readings.</td></tr> </table> This parameter is enabled only for Periodic Trigger.	EM	Log only EM Measure Readings.	RTD	Log only RTD Terminal Readings.	EM+RTD	Log EM Measure and RTD Terminal both Readings.
EM	Log only EM Measure Readings.						
RTD	Log only RTD Terminal Readings.						
EM+RTD	Log EM Measure and RTD Terminal both Readings.						
Save Method	Reading Type selection for Logging <u>Available Options:</u> Instant Min Max Average All This parameter is enabled only for Periodic Trigger.						

Sampling Rate(s)	Sampling Rate for Periodic Data Logging in seconds. <u>Range:</u> 1 to 9999 This parameter is enabled only for Periodic Trigger.
Logging Time (HH:MM:SS)	Total Logging Time in HH:MM:SS Format for Periodic Logging. This parameter is enabled only for Periodic Trigger.
File No.	File Number. <u>Range:</u> 1 to 25 This parameter is enabled only for Periodic Trigger.
File Info.	Shows the information of stored files. This information contains Logging Start Time & Date and No of Samples stored in the file.
File Delete	Delete stored file.
START LOGGING	Press F1 key while selecting this button to start the Logging.

Notes:

- *Maximum No of Reading that can be stored in,*

Logging Mode	Max. Reading
Periodic	150000
Key Press	430

- *In Periodic mode, changing of any Measure or Source parameter is not allowed. So While Periodic Logging is Running, User can't enter into MEASURE, SOURCE and DISPLAY menu. But in Key Press Logging mode, there is no restriction.*
- *In Periodic Mode, if error message like "Not Sufficient Memory" comes while starting the Logging. Try to Reduce Logging Time or Increase Sampling Period or try deleting some existing files.*
- *In Key Press Mode, If No of Samples reach its maximum limit that is 484, the next sample will start from the first overwriting the memory.*
- *While Logging is running, entering into the LOGGING menu shows below page.*

for Periodic Mode

DATA LOGGING	
Logging Running...	
No of Sample Taken	20 out of 100
Time Remaining	00:10:45
STOP LOGGING	
BACK	

for Key Press Mode

DATA LOGGING	
Logging Running...	
STOP LOGGING	
BACK	

For Periodic Mode, this page contains information of Number of Samples Taken and Time Remaining for Logging in HH:MM: SS.

- *Both Periodic and Key Press logging can be stop manually by pressing F1 key on STOP LOGGING Button. For Periodic Mode, Logging will automatically stopped when defined log time ends and a message "LOGGING DONE" pop ups.*

4.5.1 Transferring the Results to a Personal Computer:


A 32-bit Windows® software called **mCAL+.exe** is shipped together with TC 12+ if you bought the Data Logging option. Start this software just as any other Windows® software.

All communication between the PC and TC 12+ is initiated from **mCAL+.exe**.

More information of the software in mL12Im501_00.pdf document available in software CD.

4.6 CJC SETTING Page


This Page is appears in *RUN* → *MENU* → *CJC Settings*.



Parameter Name	Description / Options						
CJC Mode	CJ (Cold Junction) Temperature Mode <u>Available Options:</u> <table border="1"> <tr> <td>AUTO</td><td>CJ Temperature is TC Terminal's temperature.</td></tr> <tr> <td>MANUAL</td><td>CJ Temperature is user selectable irrespective of TC Terminal temperature.</td></tr> <tr> <td>RTD COMPENSATION</td><td>When using an external Reference Junction, TC 12+ measures or simulates the thermovoltage.</td></tr> </table>	AUTO	CJ Temperature is TC Terminal's temperature.	MANUAL	CJ Temperature is user selectable irrespective of TC Terminal temperature.	RTD COMPENSATION	When using an external Reference Junction, TC 12+ measures or simulates the thermovoltage.
AUTO	CJ Temperature is TC Terminal's temperature.						
MANUAL	CJ Temperature is user selectable irrespective of TC Terminal temperature.						
RTD COMPENSATION	When using an external Reference Junction, TC 12+ measures or simulates the thermovoltage.						
CJC Adjustment	CJ Temperature adjustment for Manual CJC Temperature.						
External RJ Sensor	The Reference Junction temperature is measured using and RTD sensor connected to RTD terminals						

4.7 Wire Select Page


This Page is appears in *RUN → MENU → WIRE SELECT*.



Parameter Name	Description / Options				
Detection Mode	Wire Detection Mode <u>Available Options only for Measure:</u> <table border="1"> <tr> <td>AUTO</td><td>Automatic detect the wire connection.</td></tr> <tr> <td>MANUAL</td><td>Manually Select the wire connection</td></tr> </table>	AUTO	Automatic detect the wire connection.	MANUAL	Manually Select the wire connection
AUTO	Automatic detect the wire connection.				
MANUAL	Manually Select the wire connection				
Wire Selection	Manually Select the wire connection <u>Available Options:</u> 2 Wire 3 Wire 4 Wire				

4.8 Alarm Page

This Page is appears in *RUN* → *MENU* → *ALARM*.



Individual alarm limit values may also be enabled/disabled using the check box preceding the alarm limit value.


When an alarm limit is exceeded, TC 12+ emits an audible alarm and the Main Reading is shown with RED Color.

To stop alarm uncheck the appropriate alarm checkbox.

Parameter Name	Description / Options
<	Alarm Low Limit Value <u>Range:</u> In accordance with Input Range & Measure Display Mode. And also it can't be greater than Alarm High Limit when High Alarm is enabled.
>	Alarm High Limit Value <u>Range:</u> In accordance with Input Range & Measure Display Mode. And also it can't be less than Alarm Low Limit when Low Alarm is enabled.

4.9 SETTING Page

This Page is appears in *RUN* → *MENU* → *SETTING*.



All the available Settings Options are given below.

- i. HART
- ii. Display
- iii. Date/Time
- iv. Calibration
- v. Battery Info.
- vi. Set Password
- vii. Factory Reset
- viii. About Us

Press F1 key to Enter into the settings of any option.

Description of all settings given below.

HART

HART (250 ohms)

NO ☒

YES ☐

EDIT | BACK

4.9.1 HART Settings

Select YES to add a Series resistor (250Ω) into the mA circuit.

You can then use this instrument together with a HART® communicator to set up and calibrate HART® devices.

This option is applicable for mA (24V) Read Power Input Type Only.

DISPLAY	
Display Intensity(%)	100
Screen Mode	Glance Screen ▼
Glance Screen Time out	100
<i>Keeping Glance Screen On uses less Battery Power</i>	
EDIT	BACK

4.9.2 Display Settings

Display Intensity	Display Brightness Settings. <u>Range:</u> 5 to 100
Screen Mode	Screen Mode <u>Available options:</u> Glance screen Always on
Glance Screen Time Out	Standby Time in second after which display will turn Off. To turn the display on press any key. <u>Range:</u> 0 to 9999 sec

DATE/TIME	
Date	1 / 5 / 13 DD MM YY
Date Format	DD/MM/YY ▼
Time	1 : 5 : 13 HH MM SS
	AM ▼
Time Format	12 Hour ▼
EDIT	BACK

4.9.3 Date/Time Settings

To set the Time + Date of the device.

There are 2 Date Format supported in this device **DD/MM/YY**&**MM/DD/YY**. This is useful only in Data Logging, to decide in which format Date to be stored.

There are 2 Time format supported in this device **24 Hour**&**12 Hour**. This is to select in which format the time should be displayed on Run page & time to be stored in Data Logging. AM/PM selection is enabled only for 12 Hour Time Format.

4.9.4 Calibration

The instrument is factory calibrated for the specified range, but due to long term drift of components, re-calibration may be necessary in some cases. For calibrating the instrument a reliable source & reliable measurement device is required. This source should be at least ten times accurate compared to the range of the instrument.


Note:

We can provide a calibration service that is traceable to international standards.

We recommend that you return the instrument to the manufacturer or an approved service agent for calibration. If you use an alternative calibration facility, make sure that it uses these standards.

The unit can be calibrated without opening it and without trim pots. To enter in calibration mode follow the steps below.

First press the MENU/ENT key in RUN mode to enter in Menu page. In Menu page select the Settings option and press F1 key to enter into the Setting mode. In setting mode select the Calibration option and press F1 key to enter into the calibration mode.




**Press F1 Key to Enter Into the Password Edit Mode.
Press UP or DOWN key to change to the Right Password value.**

Press Enter key to verify the Password. If the password is correct Measure & Source calibration options will be enabled.


To calibrate the instrument first enter the correct password. If the entered password is correct all other options will be enabled.

➤ **Procedure for calibration of EM Measure Mode**

First select the Input Type which to be calibrated.



Or



For Better Calibration Input Range is divided into two sub ranges. So For each input type, Calibration of both sub ranges need to done. The Sub Ranges of each input type is given in the below table.

Input Type	Sub Ranges	Recommended Calibration Points
mA (0.000 to 24.000 mA)	1. 0.000 to 12.000 mA	ZERO: 1.000 mA SPAN: 11.000 mA
	2. 12.000 to 24.000 mA	ZERO: 13.000 mA SPAN: 23.000 mA
V (0.000 to 30.000 V)	1. 0.000 to 15.000 V	ZERO: 1.000 V SPAN: 14.000 V
	2. 15.000 to 30.000 V	ZERO: 16.000V SPAN: 29.000V

Note:

It is not compulsory to calibrate at recommended points. User can calibrate at any points within specified Sub Range. The Sub Range is

shown on the screen. But make sure to calibrate Zero & Span in the same sub range.

Example: - Calibrating mA Input

To calibrate **ZERO for Sub Range #1**,

- Apply mA Input value near to Recommended Zero Value for Sub Range 1 (for mA sub range 1 it is 1.000mA) from reliable source device.
- For example, If apply 1.000mA from the external source. **Measured** value shows the value that has been measured by the TC 12+. If this value is 1.020 enter 1.000 value in **ZERO Actual Value** Edit Box & Press **MENU/ENT** key to calibrate the ZERO.

Similarly, for **SPAN for Sub Range #1** calibration,


- Apply mA Input value near to Recommended Span Value for Sub Range 1 (for mA sub range 1 it is 11.000mA) from reliable source device.
- For example, If apply 11.000mA from the external source. If the **Measured** value shows 10.995 enter 11.000 value in **SPAN Actual Value** Edit Box & Press **MENU/ENT** key to calibrate the SPAN.
- Follow the same procedure to calibrate Sub Range 2.
- The same procedure is applicable for other Input Type.
- To calibrate input use other source according to the input type which is ten times accurate compared to the range of the instrument.

Note:

No need to separately calibrate mA (24V) Input.

➤ Procedure for calibration of TC Measure

To enter into the TC Measure Calibration, Select the **TC** option in Calibration page and MEASURE TC option in CAL. TC page.



All Thermocouple and mV input are divided into 3 groups.

For Better Calibration Accuracy group 3 is divided into two sub ranges. So for these group, Calibration of both sub ranges need to done. The Sub Ranges of each input type is given in the below table.

TC MEASURE Group	Sub Range	Recommended Zero	Recommended Span
1	-10 to 80 mV	1	-5.000 mV
2	S -TC	1	35.000 mV
3	-10 to 250 mV	1	95.00 mV
		2	126.00 mV

Note:

It is not compulsory to calibrate at recommended points. User can calibrate at any points within specified Sub Range. The Sub Range is shown on the screen. But make sure to calibrate Zero & Span in the same sub range.

Example: - Calibrating Group-1

Select Group 1 in TC Group ListBox.

To calibrate **ZERO for Sub Range #1**,


- Apply mV Input value near to Recommended Zero Value for Sub Range 1 (for Group 1 sub range 1 it is -5.000mV) from reliable source device.
- For example, If apply -5.000mV from the external source. **Measured** value shows the value that has been measured by the TC 12+. If this value is -5.030 enter -5.000 value in **ZERO Actual Value** Edit Box & Press **MENU/ENT** key to calibrate the ZERO.

Similarly, for **SPAN for Sub Range #1** calibration,

- Apply mV Input value near to Recommended Span Value for Sub Range 1 (for Group 1 sub range 1 it is 20.000mV) from reliable source device.
- For example, If apply 20.000mV from the external source. If the **Measured** value shows 20.050 enter 20.000 value in **SPAN Actual Value** Edit Box & Press **MENU/ENT** key to calibrate the SPAN.
- The same procedure is applicable for other TC Measure Group.
- To calibrate input use other source according to the input type which is ten times accurate compared to the range of the instrument.

➤ Procedure for calibration of TC Source

To enter into the TC Source Calibration, Select the **TC** option in Calibration page and SOURCE TC option in CAL. TC page.



All Thermocouple and mV Source are divided into 3 groups.

TC SOURCE Group	Zero	Span
1	-5.000 mV	25.000 mV
2	35.000 mV	80.000 mV
3	95.00 mV	240.00 mV

Example: - Calibrating Group-1

To calibrate **ZERO**,


- Select **ZERO Measured** Edit Box, when this Edit Box is selected TC 12+ will source value that is seen in **ZERO Expected** Value (here TC 12+ will source -5.000mV).
- Now Measure the source value in Reliable Measure Unit. For Example the external measure unit is measuring -4.998mV. Then enter -4.998 value in **ZERO Measured** Edit Box & Press **MENU/ENT** key to calibrate the ZERO.

To calibrate **SPAN**,

- Select **SPAN Measured** Edit Box, when this Edit Box is selected TC 12+ will source value that is seen in **SPAN Expected** Value (here TC 12+ will source 25.000mV).
- Now Measure the source value in Reliable Measure Unit. For Example the external measure unit is measuring 25.010mV. Then enter 25.010 value in **SPAN Measured** Edit Box & Press **MENU/ENT** key to calibrate the SPAN.
- Follow the same procedure to calibrate the other output types.

➤ **Procedure for calibration of Ambient Temperature**

To enter into the Ambient Temperature Calibration, Select the **TC** option in Calibration page and Ambient Cal. option in CAL. TC page.



Example: - Calibrating CJ Temperature


CJ measured value shows the current measured temperature of the TC Terminals in the Display Unit selected in TC Setup Page. For example if it shows 25.0 °C and the real temperature of the TC terminal is 25.5 °C then enter 25.5 in Actual Editbox to calibrate CJ Temperature.

Note:

Please make sure that your unit is in proper Input TC Type and CJC is in AUTO mode.

➤ Procedure for calibration of RTD Measure

To enter into the RTD Measure Calibration, Select the **RTD** option in Calibration page and MEASURE RTD option in CAL. RTD page.



All RTD input are divided into 4 groups.

For Better Calibration Accuracy group 1 & 4 are divided into two sub ranges. So for those groups, Calibration of both sub ranges need to be done. The Sub Ranges of each input type is given in the below table.

RTD MEASURE Group		Sub Range	Recommended Zero	Recommended Span
1	0 to 400 Ohms	1	5.00 Ohms	190.00 Ohms
		2	210.00 Ohms	390.00 Ohms
2	0 to 800 Ohms	1	380.00 Ohms	790.00 Ohms
3	0 to 1600 Ohms	1	780.00 Ohms	1590.00 Ohms
4	0 to 4000 Ohms	1	1100.00 Ohms	2400.0 Ohms
		2	2600.0 Ohms	3900.0 Ohms

Note:

*It is not compulsory to calibrate at recommended points. User can calibrate at any points within specified Sub Range. The Sub Range is shown on the screen. But make sure to calibrate Zero & Span in the same sub range. Make sure unit is in **4-wire mode** during RTD Measure Mode.*

Example: - Calibrating Group-1

Select Group 1 in RTD Group ListBox.

To calibrate **ZERO for Sub Range #1**,


- Apply Resistance Input value near to Recommended Zero Value for Sub Range 1 (for Group 1 sub range 1 it is 5.00Ohms) from reliable source device.
- For example, If apply 5.00Ohms from the external source. **Measured** value shows the value that has been measured by the TC 12+. If this value is 5.02 enter 5.00 value in **ZERO Actual Value** Edit Box & Press **MENU/ENT** key to calibrate the ZERO.

Similarly, for **SPAN for Sub Range #1** calibration,

- Apply Resistance Input value near to Recommended Span Value for Sub Range 1 (for Group 1 sub range 1 it is 190.00Ohms) from reliable source device.
- For example, If apply 190.00Ohms from the external source. If the **Measured** value shows 191.00 enter 190.00 value in **SPAN Actual Value** Edit Box & Press **MENU/ENT** key to calibrate the SPAN.
- Follow the same procedure to calibrate for the Sub Range 2.
- The same procedure is applicable for other RTD Measure Group.
- To calibrate input use other source according to the input type which is ten times accurate compared to the range of the instrument.


➤ **Procedure for calibration of RTD Source**

To enter into the RTD Source Calibration, Select the **RTD** option in Calibration page and SOURCE RTD option in CAL. RTD page.



For RTD source calibration first calibrate Offset for all 4 groups.

➤ **Procedure for calibration of Offset**



- To enter into the Offset Calibration, Select the **Offset Calibration** Radiobuttonbox in **CAL. RTD SOURCE** page.

Example: - Calibrating Offset

Offset measured value for zero and span is always 0.000mV

To calibrate **ZERO**,

- Select **ZERO Measured** Edit Box, when this Edit Box is selected TC 12+ will source value that is seen in **ZERO Expected** Value (here TC 12+ will source 0.000mV).For Example the external measure unit is measuring 0.023 mV offset. Then enter 0.023 value in **ZERO Measured** Edit Box & Press **MENU/ENT** key to calibrate the ZERO.

To calibrate **SPAN**,

- Select **SPAN Measured** Edit Box, when this Edit Box is selected TC 12+ will source value that is seen in **SPAN Expected** Value (here TC 12+ will source 0.000mV).
- For Example the external measure unit is measuring 0.082 mV offset. Then enter 0.082 value in **SPAN Measured** Edit Box & Press **MENU/ENT** key to calibrate the SPAN.

➤ **Procedure for calibration of Resistance**

- All RTD Source are divided into 4 groups.

RTD SOURCE Group		Zero	Span
1	0 to 200 Ohm	1.00 Ohm	180.00 Ohm
2	200 to 400 Ohm	220.00 Ohm	380.00 Ohm
3	400 to 1000 Ohm	430.0 Ohm	980.0 Ohm
4	1000 to 4000 Ohm	1050.0 Ohm	3950.0 Ohm

Example: - Calibrating Group-1

To calibrate **ZERO**,

- Select **ZERO Measured** Edit Box, when this Edit Box is selected TC 12+ will source value that is seen in **ZERO Expected** Value (here TC 12+ will source 1.00Ohm).
- Now Measure the source value in Reliable Measure Unit. For Example the external measure unit is measuring 1.07 Ohm. Then enter 1.07 value in **ZERO Measured** Edit Box & Press **MENU/ENT** key to calibrate the ZERO.

To calibrate **SPAN**,

- Select **SPAN Measured** Edit Box, when this Edit Box is selected TC 12+ will source value that is seen in **SPAN Expected** Value (here TC 12+ will source 180.00 Ohm).
- Now Measure the source value in Reliable Measure Unit. For Example the external measure unit is measuring 182.00 Ohm. Then enter 182.00 Ohm value in **SPAN Measured** Edit Box & Press **MENU/ENT** key to calibrate the SPAN.
- Follow the same procedure to calibrate the other RTD Source Group.

BATTERY INFO.	
Level(%)	90
Voltage(mV)	4100
Current(mA)	500
Status	Charging
Time to Full(min)	30
Time to Empty(min)	-
BACK	

4.9.5 Battery Info.

This page shows the basic battery Information.

- Battery Level (Percentage)
- Battery Voltage (in mV)
- Current (in mA)
- Battery Status
- Time to Full (in min)
- Time to Empty (in min)

SET PASSWORD	
Current Password	0
New Password	0
EDIT BACK	

4.9.6 Set Password

Change Device Password.

This password has to be entered before Calibrating & Resetting Configuration Parameters.

To change password Enter Current Password. If the entered password is correct then New Password EditBox will be enabled. Then enter the New Password and press **MENU/ENT** key to store it.

FACTORY RESET	
Enter Password	0
Configuration RESET	
NO	☒
YES	☐
EDIT BACK	

4.9.7 Factory Reset

To Reset TC 12+ Parameters to its Default Value.

To Reset Enter Current Password. If the entered password is correct then Configuration RESET Radiobuttonbox will be enabled. Then select YES option and press **MENU/ENT** Key to reset Configuration.

4.9.8 About Us


This Page illustrates the Connection diagrams for valid connections to this device.

5. Maintenance & Troubleshooting

5.1 Common Problems

Problem	Possible Causes
Device Not Starting Up	• Battery Discharged • Battery Connection Loose
Reading Fluctuation/ Reading OPEN	• Wrong / Loose Connections
Error Code on status bar	• One of the peripheral not working properly. (Solution: Restart the Device if still error code showing contact factory)
Calibration Out	• Distortion in due to external noise connection (Solution: Check connection. If still out contact factory or Recalibrate Device in authorized cal-lab.)
Battery Not Charging	• Battery Connection Loose • Battery Dead

5.2 Replacing the Battery



5.3 Related Information

Most of the measurements, generations and simulations presented in this manual are straight forward: Just make the required window settings and connect the instrument under test to the active terminals and that's it!

Some cases require additional settings and things to check before you can be certain that the measurement, generation or simulation works as expected. A typical example of this is temperature measurement using a thermocouple. It is not enough to select the correct function in TC 12+. The Sensor type and the Reference Junction Mode have to be set accordingly, too. Wrong settings give erroneous results.

Whenever this additional information may be of use in a measurement, generation or simulation, text describing the function refers to one of the following chapters. An experienced may skip this supplemental text, but for a beginner we highly recommend it.

The subjects described here are:

- **Thermocouple Measurement/Simulation, Connections and troubleshooting** on page no 86.
- **Parallel Functions** in TC 12+ on page no 89.

5.3.1 Thermocouple Measurement/Simulation, Connections and troubleshooting.


To accurately measure the thermo-voltage caused by the temperature to be measured, the second thermo-voltage caused by the Reference Junction needs to be compensated. This is done using one of the Reference Junction compensation methods described in the subsequent chapters.

The Reference Junction compensation method has to be chosen both when measuring and simulating thermocouples.

➤ Internal Reference Junction

TC 12+'s Internal Reference Junction makes thermocouple measurement / simulation easy. No external connections are required, just connect the thermocouple or a thermo-voltage receiver directly to TC 12+'s "T/C" terminals. To select this compensation method, set the SCR1 field "T/C Sensor Measurement" or "T/C Sensor Simulation", make sure the Unit is a temperature unit and set the CJC Mode to "Auto".

Connection when measuring/simulating thermocouples using Internal Reference Junction Mode:




➤ **External Reference Junction**

When using an external Reference Junction, TC 12+ measures or simulates the thermo-voltage using the “T/C” terminals. The following external Reference Junction compensation methods are available, to select this compensation method, set the SCR1 field “T/C Sensor Measurement” or “T/C Sensor Simulation”, make sure the Unit is a temperature unit and set the CJC Mode to “RTD Compensation”.


➤ **External RTD:**

To be used when The Reference Junction temperature is measured using an RTD sensor connected to TC 12+’s RTD terminals.

Connection when measuring/simulating thermocouples using Reference Junction compensation method “External RTD”:



Note: If you connect an RTD sensor to the RTD connectors, there is no galvanic isolation between the thermocouple and the RTD sensor.



➤ **Manually Entered:**

To be used when The Reference Junction temperature is fixed to a temperature. The Reference Junction temperature is controlled and the controller's set point to desired temperature.

Note: this method is of use only if the accuracy of the controller is better than TC 12+'s own Reference Junction.

A compensation box is used and the Reference Junction temperature setting is set to desired temperature.

There is no Reference Junction compensation in the measuring/simulation circuit, but you want to manually enter another Reference Junction temperature.

Connection when measuring/simulating

Thermo-voltages using a temperature controller and either of the following Reference Junction compensation method: "Manually Entered"

➤ **Error situations**

The easiest way to avoid errors in thermocouple measurement and simulation is to check carefully the used wiring and the Reference Junction mode. The following table describes the typical error situations and possible causes/corrections when working with thermocouples:

PROBLEMS	CAUSE
TC 12+ (or the instrument under test when simulating thermo voltages) measures the temperature/millivolt signal, but the displayed temperature reading is all wrong. (The error may vary from 0 to about $\pm 50^{\circ}\text{C}$ depending on the type of the error)	• The thermocouple type selected in TC 12+ does not correspond with the used Thermocouple. • The selected Reference Junction mode is Not in accordance with the used wiring. • Extension or compensation cable type or Connections are incorrect. • The polarity of the cables are incorrect.
TC 12+ (or the instrument under test) displays random readings during Thermocouple measurement.	• Incorrect connections. • The wiring is broken. • Interference from a mobile phone or a radio transmitter affects the measurement.


5.3.2 Parallel Functions in TC 12+

This chapter explains what kind of simultaneous duties TC 12+ can do. All of the following tasks may run independently, but the window settings decide what is shown:

- One measurement in the measurement terminals. Electrical Measurement terminals in TC 12+.
- Either one measurement or one Source/Measure in the *Source/Measure* terminals of TC 12+.

Also: During thermocouple measurement/simulation the RTD terminals may be used for measuring the reference junction temperature (**CJC Mode** field set to **External RTD**).

Additionally, all of the connectors on the left side of TC 12+ may have an independent task. Below illustrate the Possible Parallel Functions of TC 12+.



6. General Specifications

6.1 General Specifications

Display Mode	Measure: mA/V/mV/mA(2W)/Switch-test/RTD/TC. Source: Resistance/RTD/TC.
Supported units for RTD/TC type	°C/°F/°K
RTD Measurement Current	300 uA
Maximum Resistance excitation current (simulation)	3 mA (0...650 Ω measure/source with I exec 2.0V/ Rsim (650....4000Ω)
Settling time (pulsed currents RTD simulation)	>1 ms
CJC error (For Thermocouple) Internal Reference Junction	≤ ± 0.5 °C
CJC selection	Manual / Internal / External *
Max. input voltage(EM Terminal)	30 VDC
Temperature Coefficient	≤ 30 ppm
Input Impedance Measure (EM & TC Terminal)	TC/mV/V >1MΩ mA =10 Ω
Response time	Input < 100ms Output < 100ms
Load impedance	>4.7KΩ for TC/mV
Display update rate	10 readings/ second
Isolation	500VDC between mA/V Measure and RTD/Ω /TC/mV
Data logging	Logged data is stored in a user defined file in internal memory Periodic logging: 150000 readings max
Communication Interface	USB 2.0
Operating temperature	0° to 55° C
Operating temperature when charging batteries	0° to 45° C
Storage temperature	-20° to 60° C
Relative Humidity	30% to 90% non-condensing
Warm-up time	5 Minutes

*with RTD sensor at RTD terminal for External CJC

6.2 Display & Keys

Display	2.4" TFT LCD, 262K Color, Graphical 42.72 mm x 60.26, 240x320 pixels, White LED Backlight
Keys	9 Membrane Keys

6.3 Special Features

Loop power output	24V DC, $\pm 10\%$ (24mA maximum)
HART mA Loop Resistor	250 $\Omega \pm 20\%$
Special Function	Step/Ramp functions: Automatic/Manual. $\sqrt{x}$, x^2 : for mA/V measure/source
Continuity Test	Audible sounds when resistance measure value crosses the specified threshold. (selectable up to 100 Ω)
Automatic Wire detection	Automatic detection RTD measure wire connection. (2-wire, 3-wire or 4-wire)
Switch Test	Potential free contacts Trigger level : 24V, 24mA (2V) Voltage level detection Trigger level : 0 to 30V in 1V steps

6.4 Power Supply

Battery Type	Rechargeable Li-ion battery pack, 3000mAh 3.7V
Charging Time	<5 hours
Charger supply	100-240 VAC, 50/60 Hz; Output 5V DC@1A
Battery Life on full charge	>17 hours for RTD/ Ω /TC/V/mV measure/source with minimum backlight. >9 hours for mA generation with minimum backlight.(24VDC @12mA)
Battery Status Indication	Battery symbol displayed with % power remaining

6.5 Physical

Dimensions	185.6 mm (L) x 97.1 mm (W) x 41.3 mm (H)
Housing Material	ABS Plastic
Electrical Terminals: measure:- V/mA/mA(24V)/switch	Two nos. , 2 mm safety sockets
RTD Terminals/Electrical Terminals: Measure /Source:- Resistance/RTD	Four nos. , 2 mm safety sockets
TC Terminals:- TC/mV (measure /Source)	Thermocouple minijack socket (cu type)
Weight	<500 grams
Protection	IP20

6.6 Electrical Measurement Parameters and Accuracy

Parameter	Range	Resolution	Accuracy
V	0-30.00 VDC	0.001 V	$\pm 0.02\%$ of reading ± 2 count
mA	0-24.00 mA	0.001 mA	$\pm 0.02\%$ of reading ± 2 count

6.7 Resistance Measurement 0 ... 4000 ohm

Range	Resolution	Accuracy
0....1600 Ω	10 mΩ	4 Wire Connection: 0.02% of reading $\pm$ 0.01 Ω 3 Wire Connection: 0.02% of reading $\pm$ 0.015 Ω
1600....4000 Ω	100 mΩ	4 Wire Connection: 0.02% of reading $\pm$ 0.1 Ω 3 Wire Connection: 0.02% of reading $\pm$ 0.15 Ω

6.8 Resistance Simulation 0 ... 4000 ohm

Range	Resolution	Accuracy*
0....400 Ω	10 mΩ	0.02% of reading $\pm$ 0.02 Ω
400....4000 Ω	100 mΩ	0.02% of reading $\pm$ 0.15 Ω

6.9 RTD Measurement and Simulation

1) Pt10 Pt1000, -200 850 °C

Range	Resolution	Accuracy
-200....200 °C	Pt10...Pt400: 0.01 °C Pt500,Pt1000: 0.1 °C	4 wire Measurement: 0.15°C Simulation*: 0.15 °C
200....600 °C		4 wire Measurement: 0.2 °C Simulation*: 0.25 °C
600....850 °C		4 wire Measurement: 0.3 °C Simulation*: 0.35 °C

2) Ni100, -60 180 °C

Range	Resolution	Accuracy
-60....180 °C	0.01 °C	4 wire Measurement: 0.1 °C Simulation*: 0.15 °C

3) Ni120, -80 260 °C

Range	Resolution	Accuracy
-80....260 °C	0.01 °C	4 wire Measurement: 0.1 °C Simulation*: 0.15 °C

4) Cu10, -200 260 °C

Range	Resolution	Accuracy
-------	------------	----------

-200....260 °C	0.01 °C	4 wire Measurement: 0.2 °C Simulation*: 0.8 °C
----------------	---------	---

Note: * Specification valid with an excitation current >0.2 mA (0...400 ohm),
>0.1 mA (400...4000 ohm)

** Read accuracy is based on 4-wire input. For 3-wire RTD measurements, assuming all three

RTD leads are matched, add 1.0 °C (Pt10 and Cu10), 0.6 °C (Pt50 and Cu50), and 0.4 °C

(Other RTD types) to the specifications.

6.10 Available RTD Types


- | | | |
|----------------|-----------------|-----------------|
| 1) Pt10 (385) | 6) Pt500 (385) | 11) Ni120 (672) |
| 2) Pt50 (385) | 7) Pt1000 (385) | 12) Cu10 (427) |
| 3) Pt100 (385) | 8) Pt100 (3926) | 13) Cu50 (427) |
| 4) Pt200 (385) | 9) Ni100 (672) | 14) Cu100 (427) |
| 5) Pt400 (385) | 10) Ni100 (618) | |

6.11 Thermocouple/mV Resolution and Accuracy

TC Terminal (Measure and Source)			
TC Type	Range	Resolution	Accuracy
E	-200.0 to 1000.0 °C	0.1 °C	0.3 °C
J	-200.0 to 1200.0 °C	0.1 °C	0.3 °C
K	-200.0 to 1372.0 °C	0.1 °C	0.3 °C
T	-200.0 to 400.0 °C	0.1 °C	0.3 °C
B	450.0 to 1800.0 °C	0.1 °C	0.5 °C
R	0.0 to 1750.0 °C	0.1 °C	0.5 °C
S	0 to 1750.0 °C	0.1 °C	0.5 °C
N	-200.0 to 1300.0 °C	0.1 °C	0.3 °C
mV	-10 to 80 mV	0.001 mV	+0.02% of reading ± 4uV
	-10 to 250 mV	0.01mV	±0.02% of reading ± 0.02mV

Note: temperature standard ITS-90

6.12 Enclosure Dimensions



6.13 Ordering Code

Ordering Code
TC12+

7. Disposal

For the disposal of batteries, Due to the contained pollutants, batteries must not be disposed of as household waste. They must be given to collection points designed for that purpose.

For countries outside the India, batteries and devices should be disposed of in accordance with your local waste regulations.

If you have any query please contact customer support department.