


User Manual

Model 8208-IP / 8208-XP Flame Proof 8-Channel Scanner



Sonepar India Pvt. Ltd.

B/30, GIDC Electronics Estate,
Sector-25, Gandhinagar-382016, Gujarat, India

Phone: +91 79 23287275-77

Email: support.masibus@soneparindia.com

Web: www.masibus.com

CONTENTS

CONTENTS	2
LIST OF TABLES	4
LIST OF FIGURES	4
1. INTRODUCTION	5
Foreword	5
Notice	5
Trademarks	5
Checking the Contents of the Package	5
Product Ordering Code	5
2. HARDWARE SPECIFICATION DETAIL	7
2.1 Input Specification	7
2.2 Output Specification	8
2.2.1 Digital Output - Relay	8
2.2.2 Analog Output - Retransmission Output(Optional)	8
2.3 Programming and Setting	8
2.4 Communication Specification	8
2.5 Display Specification	8
2.6 Power Supply Specification	9
2.7 Signal Isolation and Insulation Specification	9
2.8 Environmental Specification	9
3. PHYSICAL SPECIFICATION AND MOUNTING DETAILS	10
3.1 Physical Specification for IP Enclosure	10
3.2 Physical Specification for FLP Enclosure	10
4. FRONT PANEL DESCRIPTION	14
4.1 Front Panel Diagram	14
4.2 Key Function Description	15
5. WIRING GUIDELINES	16
5.1 How to Connect Wires	17
6. MENU LAYOUT	18
6.1 Parameter Flow Diagram	18
6.2 Menu Parameters- In Detail	20
7. RELAY OUTPUT	27
8. CALIBRATION PROCEDURE	32
9. MODBUS COMMUNICATION DETAIL	34
10. MISCELLANEOUS	41

11. TROUBLESHOOTING 43

LIST OF TABLES

Table 1. Product Ordering code for 8208-IP	6
Table 2. Product Ordering code for 8208-XP	6
Table 3. Input types, their ranges, accuracy and resolution	7
Table 4. Signal Isolation Specification	9
Table 5. Front Panel Description	14
Table 6. Level 1 Parameters	21
Table 7. Level 2 Parameters	22
Table 8. Level 3 Parameters	24
Table 9. Calibration Parameters	25
Table 10. Factory Reset Parameters	26
Table 11. Alarm 1 and Alarm 2 Momentary Alarm Logic	27
Table 12. Alarm 1 and Alarm 2 Maintained Alarm Logic	28
Table 13. Group Calibration Detail	33
Table 14. Function code used for Modbus	34
Table 15. Exception responses for Modbus	34
Table 16. Modbus values for OPEN, OVER, UNDER and SKIP Conditions	34
Table 17. Modbus Parameter Details for Process Value	35
Table 18. Modbus Parameter Details for Holding Register	35
Table 19. Modbus Parameter Details for Read Output Status(Read Coil) Register	37
Table 20. Input Type Selection Table	38
Table 21. Relay Logic Selection	39
Table 22. Relay Function Selection	39
Table 23. Relay Open Sensor Selection	39
Table 24. Relay Group-4 Selections	39
Table 25. Relay Group-2 Selections	39
Table 26. Relay Group-4 Type Selections	39
Table 27. Relay Group-2 Type Selections	39
Table 28. Relay Latch Selection	40
Table 29. Relay per Group Selection	40
Table 30. Com Port Baud Rate Selection	40
Table 31. Parity/Stop Bit Selection	40
Table 32. Retransmission Open Sensor Selection	40
Table 33. Retransmission Type Selection	40
Table 34. Retransmission Direction Selection	40
Table 35. Retransmission Value Selection	40
Table 36. PV Input Status Display During Burnout Condition	41
Table 37. Retramission Output Table For Open /Over /Under Condition	42

LIST OF FIGURES

Figure 1. IP Enclosure Front View	11
Figure 2. IP Enclosure Bottom View	11
Figure 3. TYPE-1 FLP Enclosure Front View	12
Figure 4. TYPE-1 FLP Enclosure Bottom View	12
Figure 5. TYPE-2 FLP Enclosure Front View	13
Figure 6. TYPE-2 FLP Enclosure Bottom View	13
Figure 7. Front Panel for IP Enclosure	14
Figure 8. Front Panel for FLP Enclosure	14
Figure 9. Terminal Connection Detail	16
Figure 10. Wiring Diagram	16
Figure 11. Level 1 Parameters	18
Figure 12. Level 2, Level 3 and Calibration Parameters	19
Figure 13. Factory Reset Parameters	20

1. INTRODUCTION

Foreword

Thank you for purchasing 8208 universal Scanner. This manual describes the basic functions and operation methods of 8208. Please read through this user's manual carefully before using the product.

Notice

The contents of this manual are subject to change without notice as a result of continuing improvements to the instrument's performance and functions

Every effort has been made to ensure accuracy in the preparation of this manual. Should any errors or omissions come to your attention, however, please inform MASIBUS Sales office or sales representative. Under no circumstances may the contents of this manual, in part or in whole, be transcribed or copied without our permission.

Trademarks

Our product names or brand names mentioned in this manual are the trademarks or registered trademarks of Masibus Automation and Instrumentation (P) Ltd. (herein after referred to as **MASIBUS**).

Adobe, Acrobat, and Postscript are either registered trademarks or trademarks of Adobe Systems Incorporated. All other product names mentioned in this user's manual are trademarks or registered trademarks of their respective companies.

Version Number : 1.01 , May 2015.

Checking the Contents of the Package

Unpack the box and check the contents before using the product. If the product is different from that which you have ordered, if any parts or accessories are missing, or if the product appears to be damaged, contact your sales representative.

Product Ordering Code

The 8208 Scanner unit has a nameplate affixed to the one side of the enclosure. Check the model and suffix codes inscribed on the nameplate to confirm that the product received is that which was ordered.

Table 1. Product Ordering code for 8208-IP

Model	No. of Channels	Input Type		Auxiliary Power Supply		Retransmission Output Type	
8208-IP	8	U	Universal	U1	85-265 VAC / 120-360 VDC	N	None
	4	1	E	U2	18-36 VDC	1	4-20 mA
		2	J			2	0-20 mA
		3	K			3	1-5 V
		4	T			4	0-5 V
		5	B			5	0-10 V
		6	R				
		7	S				
		8	N				
		9	Pt 100				
		A	-10 to 20 mV				
		B	0-75 mV				
		C	0-100 mV				
		D	0.4-2V				
		E	0-2 V				
		F	4-20 mA				
		G	0-20 mA				
		H	0-5 V				
		I	1-5 V				
		J	0-10 V				

Table 2. Product Ordering code for 8208-XP

Model	No. of Channels	Input Type		Auxiliary Power Supply		Retransmission Output Type	
8208-XP	8	U	Universal	U1	85-265 VAC / 120-360 VDC	N	None
	4	1	E	U2	18-36 VDC	1	4-20 mA
		2	J			2	0-20 mA
		3	K			3	1-5 V
		4	T			4	0-5 V
		5	B			5	0-10 V
		6	R				
		7	S				
		8	N				
		9	Pt 100				
		A	-10 to 20 mV				
		B	0-75 mV				
		C	0-100 mV				
		D	0.4-2V				
		E	0-2 V				
		F	4-20 mA				
		G	0-20 mA				
		H	0-5 V				
		I	1-5 V				
		J	0-10 V				

2. HARDWARE SPECIFICATION DETAIL

2.1 Input Specification

NO. OF CHANNEL	8 or 4
APPLICABLE STANDARDS	DIN (ITS-90) for Thermocouple and RTD
INPUT TYPE	As specified in Table 3
SAMPLING PERIOD PER INPUT	100 ms for TC and Linear Input and 200 ms for RTD
RESOLUTION	17 bit
BURNOUT DETECTION	Functions for TC, RTD, linear input signal. (It detects whether sensor is connected or not) ALL Relay output can be selected for Burnout Condition. i.e. Open sensor Up scale or Down Scale.
MEASUREMENT CURRENT	1 mA
INPUT IMPEDANCE	>1 Mohm for thermocouple/ mV/RTD/Volts inputs & 100 ohms for mAmp input.
NOISE REJECTION RATIO	• NMRR (Normal mode rejection ratio) > 40 dB (50/60 Hz) or more • CMRR (Common mode rejection ratio) >120 dB (50/60 Hz) or more
ALLOWABLE WIRING RESISTANCE FOR RTD	Maximum 15 ohms/wire (Conductor resistance between three wires should be equal).

Table 3. Input types, their ranges, accuracy and resolution

Type	Range	Accuracy	Resolution
E	-200 to 1000°C	$\pm 0.1\%$ of instrument range ± 1 digit for temperature equal to or higher than 0° C $\pm 0.25\%$ of instrument range ± 1 digit for temperature below 0° C	0.1°C
J	-200 to 1200°C		
K	-200 to 1370°C		
T	-200 to 400°C		
B	450 to 1800°C	$\pm 0.25\%$ of instrument range ± 1 digit	1°C
R	0 to 1750°C		
S	0 to 1750°C		
N	-200 to 1300°C		
RTD	-199.9 to 850.0°C	$\pm 0.1\%$ of instrument range ± 1 digit	0.1°C
0 to 75mV	-1999 to 9999	$\pm 0.1\%$ of range ± 1 digit	1 Count
0 to 100mv			
0.4 to 2V			
0 to 2V			
0-20 mA*			
4-20 mA*			
0 to 5V			
1 to 5V			
0 to 10V			
-10 to 20mV			

*For DC current input, 100 Ohms (0.1%, 25 ppm) shunt resistor must be connected externally. For DC current and Voltage input, Scaling is possible and decimal point is selectable.

2.2 Output Specification

2.2.1 Digital Output - Relay

NUMBER OF OUTPUTS	4
PURPOSE	Alarm or trip output
OUTPUT SIGNAL	Two terminals (C and NO) (Jumper selectable for NO or NC selection)
RELAY CONTACT RATING	250 VAC / 30 VDC @ 2A
NO. OF RELAY OPERATION	1 X 10 ⁵ @ rated current

2.2.2 Analog Output - Retransmission Output(Optional)

NUMBER OF OUTPUTS	1
OUTPUT SIGNAL	0-20 mA, 4-20 mA, 0-5 V, 1-5 V or 0-10 V DC(Voltage or current output can be selected through software and internal jumper settings)
LOAD RESISTANCE	500 ohms Max. Or less for current output. 3k or higher for voltage output
OUTPUT ACCURACY	±0.25% of span

2.3 Programming and Setting

KEYPAD	4-keys (Menu, Escape / A/M , Shift/Down/ ACK Capsense membrane keypad provided for modification of all control and functional parameters.
MEMORY	Non volatile, restored after power loss

2.4 Communication Specification

NO. OF COMMUNICATION PORT	1-RS485
COMMUNICATION TYPE	Half duplex/Asynchronous
COMMUNICATION PROTOCOL	MODBUS RTU (Baud rate and Parity bit are selectable). All parameters are Configurable through MODBUS Protocol.
MAXIMUM NO. OF UNITS	32
COMMUNICATION ERROR DETECTION	CRC Check

2.5 Display Specification

DATA DISPLAY	4-digits, 7-segment, Red, 0.56" character height
CHANNEL NO. DISPLAY	2-digits, 7-segment, Green , 0.56" character height
RELAY GROUP DISPLAY	1-digits, 7-segment, Red, 0.56" character height
STATUS LEDs	16-Red LEDs for Alarms status, 4-Red LEDs for Relay status, 1-Red LED Manual mode status, 1-Red LED Fault status, 2-Green LEDs for Communication.

2.6 Power Supply Specification

RATED VOLTAGE	85-265VAC-50/60Hz ⁽¹⁾ / 100-300VDC or 18-36VDC (Optional)
POWER CONSUMPTION	Max. 15 VA

⁽¹⁾ Unit can also work on 120-360VDC Power Supply range.

2.7 Signal Isolation and Insulation Specification

ISOLATION RATING	Withstanding Voltage: 1) Between primary terminals ⁽¹⁾ and secondary terminals ⁽²⁾ : 1500VAC for 1 minute 2) Between secondary terminals: 500V AC for 1 minute
SIGNAL ISOLATION	As specified in Table 4
INSULATION RESISTANCE	> 20 Mohms at 500V DC

Table 4. Signal Isolation Specification

Sr No	Signals	Signal Isolation
1	Power Input	Isolated from other input/output terminals and internal circuit
2	Analog Inputs	Not isolated from other analog input terminals and from the internal circuit. But isolated from other input/output terminals.
3	RS-485 Communication	Isolated from other input/output terminals and internal circuit
4	Relay contacts	Isolated between contact output terminals and from other Input/output terminals and internal circuit

2.8 Environmental Specification

AMBIENT TEMPERATURE	0 to 70°C
STORAGE TEMPERATURE	0 to 85°C
HUMIDITY	30% to 95% RH (Non-Condensing)
TEMPERATURE COEFFICIENT	FOR PV (Main input) less than 100ppm. FOR Retransmission less than 150ppm.
INSTRUMENT WARM-UP TIME	30 minutes after power on

3. PHYSICAL SPECIFICATION AND MOUNTING DETAILS

3.1 Physical Specification for IP Enclosure

MOUNTING METHOD	Wall Mounting with the help of 4 NOS bolts of size M8
UNIT	mm
WEIGHT	Max. 4 Kg
TYPE OF PROTECTION	NEMA 4
IP PROTECTION	IP 65
MATERIAL	Enclosure and door: 1.6 mm Thick M.S. Sheet Metal Fabricated
CASE COLOR	Powder Coated
ENCLOSURE DIMENSION	200 mm (W) X 200 mm (H) X 120mm (D)
CABLE ENTRY SIZE / NO	PG11– 06 NOS

Note: *Standard 6 nos. PG11 glands are supplied for both 4/8 channel Scanner. In 8 channel scanner up to 12 nos.PG11 glands can be provided. If required then please consult factory.

3.2 Physical Specification for FLP Enclosure

MOUNTING METHOD	Wall Mounting with the help of 4 NOS bolts of size M8
UNIT	mm
WEIGHT	Max. 6 Kg
TYPE OF PROTECTION	Ex-d AS PER IS:2148-07 (IS/IEC 60079-1 :2007)
IP PROTECTION	IP 65
AREA CLASSIFICATION	GAS GROUPS IIA & IIB AS PER IS: 2148-04 (IS/IEC 60079-1 :2007)
MATERIAL	ALUMINIUM ALLOY LM-6
PAINT	ANTI CORRSIVE EPOXY LIGHT GREY SHADE -631 OF IS:5
HARDWARE	HIGH TENSIL ZINC PASSIVATED I STAINLESS STEEL (SS-304)
ENCLOSURE DIMENSION	Type 1 : 220 mm (W) X 220 mm (H) X 140mm (D) Type 2 : 265 mm (W) X 265 mm (H) X 150mm (D)
CABLE ENTRY SIZE / NO	1" ET – 3 NOS

Note : Check out the next page for IP and FLP enclosure Drawing




Figure 1. IP Enclosure Front View




Figure 2. IP Enclosure Bottom View




Figure 3. TYPE-1 FLP Enclosure Front View




Figure 4. TYPE-1 FLP Enclosure Bottom View




Figure 5. TYPE-2 FLP Enclosure Front View




Figure 6. TYPE-2 FLP Enclosure Bottom View

4. FRONT PANEL DESCRIPTION

4.1 Front Panel Diagram




Figure 7. Front Panel for IP Enclosure




Figure 8. Front Panel for FLP Enclosure

Table 5. Front Panel Description

Name of Part	Function
Process Value Display(DATA window)	Displays Process Value. Display Parameter Name When You Set Parameter. Displays Error Message When An Error Occurs.
Channel No. Display (CHANNEL)	Displays Channel Number in run mode.
Group No. Display (GROUP)	Displays Group Number for Relay Mapping.
Relay Indicator LED (RL1, RL2, RL3, & RL4)	When Respective Relay LED Lits (In Red).
Alarm1(AL1) Indicator LEDs for Channel-1 to 8	When Alarm1 Occurs, Respective Alarm LED for Channel-1 to 8 will Lit (In Red).
Alarm1(AL2) Indicator LEDs for Channel-1 to 8	When Alarm2 Occurs, Respective Alarm LED for Channel-1 to 8 will Lit (In Red).
Auto/Manual Indicator LED (MAN)	If LED is on, it indicates Manual mode and if LED is off Auto Mode.
Communication Indicator LED(T, R)	When Communication on, two LEDs blink.

4.2 Key Function Description

Keys	Operation
MENU/ENTER KEY 	It is used to enter in the sub menu (various levels) and save the parameters to nonvolatile memory, when user setting a proper data by Increment and shift key for parameter configuration.
ESCAPE / AUTO MANUAL KEY    	It is used to come out from any sub menu (various levels) to the run mode. In Run Mode, it can be used to switch between auto to manual mode and manual to auto mode.
INCREMENT KEY 	It is used to increment the parameter for selection. Value of parameter can be incremented by pressing this key. When first time increment key pressed, DP (decimal point) in SV display blink, so user can modify the value with increment key. It is used to increment the value in particular digit. Value can be incremented from 0- 9 and from '9' again it rollovers to '0'.
SHIFT /DECREMENT/ ACKNOWLEDGEMET KEY    	It is used to Shift the digit to set the parameter as describe in increment key when DP (decimal point) started to blink. Menu key is used to go forward to show next parameter and Shift key is used to go backward to show previous parameter. In Run mode, it can be used to give Acknowledge for ALARM and TRIP.

5. WIRING GUIDELINES




Figure 9. Terminal Connection Detail




Figure 10. Wiring Diagram

5.1 How to Connect Wires



RISK OF ELECTRICAL SHOCK

Before carrying out wiring, turn off the power to the controller and check that the cables to be connected are not alive with a tester or the like because there is a possibility of electric shock.



NOTE:

- All wiring must confirm to appropriate standards of good practice and local codes and regulations. Wiring must be suitable for Voltage, Current and temperature rating of the system.
- Provide power from a single-phase instrument power supply. If there is a lot of noise in the power line, insert an insulating transformer into the primary side of the line and use a line filter on the secondary side. Do not place the primary and secondary power cables close to each other.
- For thermocouple input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires. Do not connect **Terminal – 1A, 2A , 3A, 4A, 5A, 6A, 7A or 8A** when thermocouple or linear input is selected.
- Use repeater after each set of 32 instruments connected in RS-485 Communication.
- Unused terminals should not be used as jumper points as they may be internally connected, which may cause damage to the unit.



CAUTION:

High voltage transients may occur when switching inductive loads such as some contactors or solenoid valves. Through the internal contacts, these transients may introduce disturbances which could affect the performance of the instrument.

For this type of load it is highly recommended that a “sunbber” is connected across the normally open contact of the relay switching though load. The sunbber recommended consists of a series connected resistor/capacitor (typically **15nF/100 Ohms**). A sunbber will also prolong the life of the relay contacts.

A sunbber should also be connected across the output of a tric output to prevent false triggering under line transient conditions

6. MENU LAYOUT

6.1 Parameter Flow Diagram




Figure 11. Level 1 Parameters




Figure 12. Level 2, Level 3 and Calibration Parameters




Figure 13. Factory Reset Parameters

6.2 Menu Parameters- In Detail

- Run Mode :**

Following parameters can view or change during run time.

- Immediately after powering, unit will run in Auto Mode. In auto mode channel will scan automatically according to scan time selection (1-250 second).

- Press A/M Key in run mode, Channel number scanning on display is stopped. By pressing increment key, we can change channel number manually.
- Press Shift/Decrement / ACK key in run mode, relay acknowledgement can be done.

• **Other Modes :**

For entering in Menu, press Menu/Enter key in RUN mode. There are total Five levels in Menu. By pressing increment or decrement key, mode can be changed. To enter into any mode press Menu/enter key again.

1. Level 1(Programming Mode)
2. Level 2(Configuration mode)
3. Level 3(Configuration Mode)
4. Calibration Mode
5. Factory Reset Mode

The tables below show the description and menu detail of the all the modes. In general to enter into any menu Or to edit sub menu, press Menu/Enter key, to change the submenu parameter press increment or decrement key. To come out from any menu press Esc key.

Level – 1:-

Pressing MENU key DATA window shows **LVL1** (LVL1) message. Press MENU key again PV Display shows **pWd** (PWD) message, press increment key twice to select password and then press MENU key to enter into Level-1. DATA window shows **SP.1** (SP.1) message and by pressing increment key, DATA window shows Set Point-1 Value Use Inc and shift key to modify value. OR press MENU key again to change Set-point 1 for Channel 2. ESCAPE KEY will use to come out SP.1

Table 6. Level 1 Parameters

LEVEL 1				
Parameter (DATA window)		Setting name and description	Default value	Shows only if
Symbol	Name			
pwd (PWD)	Level-1 Password	0 to 9999	0000	-
Sp.1 (SP.1)	Target Set point-1	SetPoint-1 for Channel 1 to 8.	0100 (for all 8 channel)	-
SP.2 (SP.2)	Target Set point-2	SetPoint-2 for Channel 1 to 8.	0200(for all 8 channel)	Relay group is selected 2
Hys (HYS)	Hystresis	Hystresis for Channel 1 to 8.	0002(for all 8 channel)	-

LEVEL 2:-

Pressing MENU key DATA window shows **LvL2** (LvL2) message. Press MENU key again DATA window shows **pwd** (PWD) message, press increment key twice to select password and then press MENU key to enter into Level-2. Following parameters can be configured in LEVEL – 2.

Table 7. Level 2 Parameters

LEVEL 2:				
Parameter (DATA Window)		Setting name and description	Default value	Shows only if
Symbol	Name			
pwd (PWD)	Level-2 Password	0 to 9999	0000	-
inpt (inP.t)	PV Input Type (E, J, K, T Etc.)	Follow Table 3(Input type for 1-8 channel)	K-TC(for all 8 channel)	-
Pv.hi (PV.HI)	Process value range high setting (PV high > PV low)	Range of the sensor /- 1999 to 9999 (for linear input types)(1-8 Channel)	1370(for all 8 channel)	-
Pv.lo (PV.LO)	Process value range lower setting	Range of the sensor /- 1999 to 9999 (for linear input types)(1-8 Channel)	-200(for all 8 channel)	-
dp (dP)	Decimal Point Setting Only applicable for Linear input type is selected	0 to 3(1 – 8 Channel)	0(for all 8 channel)	-
RI.lg (rL.LG)	Relay Logic(Applicable for 4-RELAY)	nrml / flsf 0:Noraml 1:Fail Safe	Normal(for all 4 Relay)	-
RI.fn (rL.Fn)	Relay Function(Applicable for 4-RELAY)	ALRM / TriP 0:ALARM 1:TRIP	Alarm(for all 4 Relay)	-
RI.dl (rL.dL)	Relay Delay(Applicable for 4-RELAY)	1 to 99 seconds	1 second(for all 4 Relay)	-
RI.o.s (rL.o.S)	Relay Open sensor(Applicable for 4-RELAY)	up / DoWn 0:DOWN 1:UP	Up Scale(for all 4 Relay)	-
RI.mp (rL.mp)	Relay mapping (Applicable for 1 -8 Channel)	See Relay Configuration	Refer Note:1	-
RI.tp (rL.tp)	Relay Group Type	See Relay Configuration	Refer Note:2	-

- Relay Configuration :

Relay configuration depends on selection of Relay group i.e. Relay group 2 or Relay group 4 in Level-3.

Relay Group - 2:

If relay group – 2 is selected, there will be two group of relay. Each group has two relay. (G-1 and G-2).

G-1 means RELAY 1 and RELAY 3

G-2 means RELAY 2 and RELAY 4

Example:

CHANNEL NO	NONE	G-1	G-2
1		✓	
2			✓
3	✓		
4		✓	
5			✓
6			✓
7		✓	
8			✓

Note:

- Both Groups can not be selected for single Channel.
- None means no group is selected for particular channel.

Relay Type can be selected as shown below:

Relay Group	Relay Type
G – 1	High/ Very High (H-VH) or Very Low /Low (VL-L) or Low/High (L-H)
G – 2	High/ Very High (H-VH) or Very Low /Low (VL-L) or Low/High (L-H)

Relay Group - 4:

If relay group – 4 is selected, there will be four group of relay. Each group has one relay. (G-1, G-2, G-3 and G-4).

G-1 means RELAY 1

G-2 means RELAY 2

G-3 means RELAY 3

G-4 means RELAY 4

Example:

CHANNEL NO	NONE	G-1	G-2	G-3	G-4
1		✓			
2	✓				
3			✓		
4					✓
5				✓	
6	✓				
7		✓			
8			✓		

Note:

- More than one Group can not be selected for single Channel.

2) None means no group is selected for particular Channel.

Relay Type can be selected as shown below:

Relay Group	Relay Type
G - 1	Low ON (L) or High ON (H)
G - 2	Low ON (L) or High ON (H)
G - 3	Low ON (L) or High ON (H)
G - 4	Low ON (L) or High ON (H)

For relay functionality Refer Relay outputs ().

LEVEL – 3:

Pressing MENU key DATA window shows **LvL3** (LvL3) message. Press MENU key again DATA window shows **pwd** (PWD) message, press increment key twice to select password and then press MENU key to enter into Level-3. Following parameters can be configured in LEVEL – 3.

Table 8. Level 3 Parameters

LEVEL 3:				
Parameter (DATA Window)		Setting name and description	Default value	Shows only if
Symbol	Name			
pwd (PWD)	Level-3 Password	0 to 9999	0000	-
Skip (skip)	Channel skip/Unskip selection.	yes / no 0:NO 1:YES	0(for all 8 channel)	-
RI.IH (rL.LH)	Relay Latch	on / off 0:OFF 1:ON	0	-
RI.Gp (rL.GP)	Relay Group	RGP.4 / rGP.2 0:Relay Group-4 1:Relay Group-2	1	-
SCAn (SCAn)	Scan Time	1 to 250 seconds	1	-
A.CJC (A.CJC)	Auto cold junction(Only applicable for TC input type	yes / no 0:NO 1:YES	1	-
F.CJC (F.CJC)	Fix cold junction(Only applicable for TC input type	0.0 to 60.0 Deg C	0.0 Deg C	-
Sr.no (Sr.no)	Unit ID	1 to 247	1	-
BAUd (Baud)	Communication Baud rate	9600 / 19.2K 0:(9600) – 9600 bps 1:(19.2K) – 19.2 Kbps	19.2k bps	
Pr.St (Pr.St)	Parity/Stop bit selection	p.n.S.1 / P.n.S.2 / P.o.s1 / P.ES.1	No parity /Stop bit -	

		0:(P.N.S.1)-parity none - stop bit-1 1:(P.N.S.2)-parity none - stop bit-2 2:(P.O.S.1)-parity odd - stop bit-1 3:(P.E.S.1)-parity even - stop bit-1	2	
T.out (t.out)	Timeout for display back to Run Mode	10 to 100 Seconds	60	-
RT.o.S (rt.o.s)	Retrasmission Open sensor	up / DoWn 0:DOWN 1:UP	1	-
Rt.tp (rt.tp)	Retransmission Output Type	0-20/4-20/ 0-5v/1-5v/ 0-10v 0:(0-20) – 0-20mA 1:(4-20) – 4-20mA 2:(0 - 5) – 0 – 5volt 3:(1 - 5) – 1 – 5volt 4:(0 – 10) - 0 -10volt	1	-
Rt.dr (rt.dr)	Retransmission direction	Dir / rev 1:(dir) 0: (rev)	1	-
Rt.CH (rt.CH)	Retransmission Channel	1 to 8 channel	1	-
Rt.rd (rt.rd)	Retransmission Channel Value	MAx / MIn 1:(Max) 0: (Min)	1	-
S.Pwd (S.PWD)	Password Set password to lock selected level	0 to 9999	0	-

Calibration :-

Pressing MENU key, DATA window shows **CAL** (CAL) message. Press MENU key again, DATA window shows **pwd** (PWD) message, press increment key twice to select password and then press MENU key to enter into Calibration.

Table 9. Calibration Parameters

Calibration:				
Parameter (DATA Window)		Setting name and description	Default value	Shows only if
Symbol	Name			
pwd (PWD)	Password	0 to 9999	0000	-
amb (Amb)	Ambient	Ambient adjustment	-	-

CAL.Z (CAL.Z)	Thermocouple, Rtd and Linear Zero Calibtriaon	Depending on PV sensor type selected	-	-
CAL.S (CAL.S)	Thermocouple, Rtd and Linear Span Calibtriaon	Depending on PV sensor type selected	-	-
Rtr.Z (rtr.Z)	Retransmission voltage and current Zero calibration	Depending on Retrasmission type selected	-	-
Rtr.S (rtr.S)	Retransmission voltage and current Span calibration	Depending on Retrasmission type selected	-	-

Factory Reset Parameters:-

Pressing MENU key, DATA window shows **F.RST** (F.rST) message. Press MENU key again, DATA window shows **pwd** (PWD) message, press Increment key twice to select password and then press MENU key to enter into Factory Reset.

Table 10. Factory Reset Parameters

Factory Reset Mode:				
Parameter (DATA window)		Setting name and description	Default value	Shows only if
Symbol	Name			
Pwd (Pwd)	Password	0 to 9999	-	-
L.def (L.DEF)	LOAD Default	CAL\PARA\ all (CAL)\(PARA)\(ALL) CAL- Only calibration set to default value PARA- All parameters excluding calibration will set to default value ALL- Calibration and parameters will set to default value	-	-

7. RELAY OUTPUT

Following function can be set for Relay outputs.

Relay Logic (Direction):

Relay Logic means Relay contact can be changed from NO – NC OR NC – NO. If relay logic is selected Normal, when Fault occur Relay contact will change from NC to NO. If relay logic is selected Fail Safe, when Fault occur Relay contact will change from NO to NC.

Relay Function: Relay function can be selected as ALARM or TRIP.

Relay Delay: A time delay can be provided for the actual output.

Relay Open Sensor : Open sensor up scale or down scale can be selected for each relay output.

Relay Mapping: Refer Menu layout LEVEL - 2

Relay Types: Various alarm operations are shown in the reference figure. (High, Low, Very High-High, Low-Very Low, High- Low)

For relay types selection Refer Menu layout LEVEL – 2.

Relay logic table:

Table 11. Alarm 1 and Alarm 2 Momentary Alarm Logic

ALARM 1

MOMENTARY ALARM

(when in abnormal condition ack not pressed)

CONDITION			NORMAL	ABNORMAL	UP (O/S)	DOWN (O/S)	ACK **	NORMAL *	ACK ***
HIGH	ALARM LATCH	LAMP	OFF	FLASH	FLASH	OFF		FLASH	OFF
	YES RELAY		OFF	ON	ON	OFF		OFF	OFF
	ALARM LATCH	LAMP	OFF	FLASH	FLASH	OFF		OFF	OFF
	NO RELAY		OFF	ON	ON	OFF		OFF	OFF
LOW	TRIP	LAMP	OFF	FLASH	OFF	OFF		FLASH	OFF
		RELAY	OFF	ON	OFF	OFF		ON	OFF
	ALARM LATCH	LAMP	OFF	FLASH	OFF	FLASH		FLASH	OFF
	YES RELAY		OFF	ON	OFF	ON		OFF	OFF
VLOW	ALARM LATCH	LAMP	OFF	FLASH	OFF	FLASH		FLASH	OFF
	YES RELAY		OFF	ON	OFF	ON		OFF	OFF
	ALARM LATCH	LAMP	OFF	FLASH	OFF	FLASH		OFF	OFF
	NO RELAY		OFF	ON	OFF	ON		OFF	OFF
	TRIP	LAMP	OFF	FLASH	OFF	OFF		FLASH	OFF
		RELAY	OFF	ON	OFF	OFF		ON	OFF

ALARM AL2

MOMENTARY ALARM

(when in abnormal condition ack not pressed)

CONDITION			NORMAL	ABNORMAL	UP (O/S)	DOWN (O/S)	ACK **	NORMAL *	ACK ***
VHIGH	ALARM	LATCH	OFF	FLASH	FLASH	OFF		FLASH	OFF
	YES	RELAY	OFF	ON	ON	OFF		OFF	OFF
	ALARM	LATCH	OFF	FLASH	FLASH	OFF		OFF	OFF
	NO	RELAY	OFF	ON	ON	OFF		OFF	OFF
HIGH	TRIP	LAMP	OFF	FLASH	OFF	OFF		FLASH	OFF
		RELAY	OFF	ON	OFF	OFF		ON	OFF
	ALARM	LATCH	OFF	FLASH	FLASH	OFF		FLASH	OFF
	YES	RELAY	OFF	ON	ON	OFF		OFF	OFF
LOW	ALARM	LATCH	OFF	FLASH	OFF	FLASH		FLASH	OFF
	YES	RELAY	OFF	ON	OFF	ON		OFF	OFF
	ALARM	LATCH	OFF	FLASH	OFF	FLASH		OFF	OFF
	NO	RELAY	OFF	ON	OFF	ON		OFF	OFF
	TRIP	LAMP	OFF	FLASH	OFF	OFF		FLASH	OFF
		RELAY	OFF	ON	OFF	OFF		ON	OFF
	ALARM	LATCH	OFF	FLASH	OFF	FLASH		FLASH	OFF
	YES	RELAY	OFF	ON	OFF	ON		OFF	OFF

Table 12 Alarm 1 and Alarm 2 Maintained Alarm Logic

ALARM AL1

MAINTAINED ALARM

(when in abnormal condition ack is pressed)

CONDITION			NORMAL	ABNORMAL	UP (O/S)	DOWN (O/S)	ACK **	NORMAL *	ACK ***
HIGH	ALARM	LATCH	OFF	FLASH	FLASH	OFF	STEADY	STEADY	OFF
	YES	RELAY	OFF	ON	ON	OFF	OFF	OFF	OFF
	ALARM	LATCH	OFF	FLASH	FLASH	OFF	STEADY	OFF	OFF
	NO	RELAY	OFF	ON	ON	OFF	OFF	OFF	OFF
LOW	TRIP	LAMP	OFF	FLASH	OFF	OFF	STEADY	STEADY	OFF
		RELAY	OFF	ON	OFF	OFF	ON	ON	OFF
	ALARM	LATCH	OFF	FLASH	OFF	FLASH	STEADY	STEADY	OFF
	YES	RELAY	OFF	ON	OFF	ON	OFF	OFF	OFF
VLOW	ALARM	LATCH	OFF	FLASH	OFF	FLASH	STEADY	OFF	OFF
	YES	RELAY	OFF	ON	OFF	ON	OFF	OFF	OFF
	ALARM	LATCH	OFF	FLASH	OFF	FLASH	STEADY	OFF	OFF
	NO	RELAY	OFF	ON	OFF	ON	OFF	OFF	OFF
	TRIP	LAMP	OFF	FLASH	OFF	OFF	STEADY	STEADY	OFF
		RELAY	OFF	ON	OFF	OFF	ON	ON	OFF
	ALARM	LATCH	OFF	FLASH	OFF	FLASH	STEADY	STEADY	OFF
	YES	RELAY	OFF	ON	OFF	ON	OFF	OFF	OFF

ALARM AL2

MAINTAINED ALARM

(when in abnormal condition ack is pressed)

CONDITION			NORMAL	ABNORMAL	UP (O/S)	DOWN (O/S)	ACK **	NORMAL *	ACK ***
VHIGH	ALARM LATCH YES	LAMP RELAY	OFF OFF	FLASH ON	FLASH ON	OFF OFF	STEADY OFF	STEADY OFF	OFF OFF
	ALARM LATCH NO	LAMP RELAY	OFF OFF	FLASH ON	FLASH ON	OFF OFF	STEADY OFF	OFF OFF	OFF OFF
	TRIP	LAMP RELAY	OFF OFF	FLASH ON	OFF OFF	OFF OFF	STEADY ON	STEADY ON	OFF OFF
HIGH	ALARM LATCH YES	LAMP RELAY	OFF OFF	FLASH ON	FLASH ON	OFF OFF	STEADY OFF	STEADY OFF	OFF OFF
	ALARM LATCH NO	LAMP RELAY	OFF OFF	FLASH ON	FLASH ON	OFF OFF	STEADY OFF	OFF OFF	OFF OFF
	TRIP	LAMP RELAY	OFF OFF	FLASH ON	OFF OFF	OFF OFF	STEADY ON	STEADY ON	OFF OFF
LOW	ALARM LATCH YES	LAMP RELAY	OFF OFF	FLASH ON	OFF OFF	FLASH ON	STEADY OFF	STEADY OFF	OFF OFF
	ALARM LATCH NO	LAMP RELAY	OFF OFF	FLASH ON	OFF OFF	FLASH ON	STEADY OFF	OFF OFF	OFF OFF
	TRIP	LAMP RELAY	OFF OFF	FLASH ON	OFF OFF	OFF OFF	STEADY ON	STEADY ON	OFF OFF

Notes :

* means normal condition after abnormal has occurred



** means ack pressed in abnormal condition

*** means ack pressed in normal condition after abnormal has already occurred.


Upon pressing Shift/Decrement key for 3 seconds, acknowledgement will be given for alarm and trip relay in abnormal condition.



Alarm Latch function applicable only for ALARM, there is no affect when TRIP Selected as a relay function LEVEL – 2.

Basic RELAY Function:



RELAY GROUP - 4





RELAY GROUP - 2

8. CALIBRATION PROCEDURE

Calibration is provided for ambient temperature, PV sensor input, Retransmission output. First select the calibration function as described below and then follow the procedure depending on the parameter to be calibrated. The sequences of parameters that will be available for calibration are listed below:

- Ambient temperature adjustment
- PV Sensor input
- Retransmission output (calibration for voltage or current)

Ambient temperature adjustment:

This menu will come up only if; the input sensor selected is Thermocouple type.

PV display shows **Amb** (Ambient temperature adjusts). PV display shows ambient temperature measured by the controller and by applying old calibration data.

DP of last digit will blink to indicate that the value can be changed. Use Inc/Shift key to adjust it to desired value. Once the desired value set and press MENU key, the blinking DP will go off to indicate that the value has been registered. The controller will automatically save all the new calculations. Ambient temperature adjustment is over.

Press MENU key to calibrate other parameters or press Escape key to come out to normal operation.

PV input sensor calibration:

When user enters in calibration menu, PV display shows message **ZERO** (Thermocouple/Linear/RTD) for sensor input span calibration for Thermocouple Linear input and RTD type. Feed sensor input using a calibrator, such that process value is close to lower range value.

Note: The controller allows the user to calibrate sensor's input anywhere in the range, but it is recommended that it should be calibrate the input at points close to lower and upper range values.

DP of last digit will blink to indicate that the value can be changed. Use Inc/Shift key to correct the displayed reading to the desired process value and press MENU key. The controller will display message **wait** (wait) in the PV display to indicate that it is doing the necessary calculations. When the calculations are over, the new calibration values are stored automatically.

PV shows the message **SPAN** (calibration SPAN). PV display shows process value corresponding to input sensor value with old calibration data. Feed sensor input using a calibrator, such that process value is close to sensor's upper range value. Use Inc/Shift key to arrive at the desired process value. Press MENU key to register the changes.

The controller will display message **wait** (wait) in the PV display to indicate that it is doing the necessary calculations. Depending on the situation, this process may take few seconds to calibrate. Zero and Span calibration is over

In case, the controller cannot complete the calibration due to any reason, it will hold previous calibration parameters. Calibration for input sensor is over.

Retransmission output calibration (Voltage/current output) (Optional):

Press set key repeatedly, till PV display shows message **rtr.Z** (retransmission output zero calibration). SV display shows the value being outputted on Retransmission output terminals. Measure the value using a highly accurate digital multi meter. Use Inc/Shift key to correct the displayed reading to the measured value. Press ENT key. The controller will store zero calibration value. Press MENU key to calibrate retransmission output span calibration menu.

PV shows the message **rtr.S** (retransmission output span calibration). SV display shows the value being outputted on retransmission output terminals. Measure the value. Use Inc/Shift key to correct the displayed reading to the measured value. Press ENT key. When the calculations are over, the new calibration values are stored automatically. Calibration for Retransmission output is over. Press MENU key to calibrate other parameters or press Escape key to come out to normal operation.

Table 13. Group Calibration Detail

Group NO	Input type	Calibration for input
1	E,J,K,T,N,0-75mv,0-100mv	Either of any input
2	Pt-100(RTD)	Specific input
3	B,R,S,-10 to 20mv	Either of any input
4	0-2V,0.4-2V,4-20mamp,0-20mamp	Either of any input
5	0-10V,0-5v,1-5V	Either of any input

NOTE:

If you calibrate any input from any group i.e. I/P E-TC from Group – 1 then calibration is not required for other input types from Group-1.

9. MODBUS COMMUNICATION DETAIL

The MODBUS Communications protocol as RS-485 or RS-232 interface module is installed. Only RTU mode is supported. Data is transmitted as 8-bit binary bytes with 1 start bit, 1/2 stop bit and optional parity checking (None, Even, Odd). Baud rate may be set to 9600 and 19200.

Table 14. Function code used for Modbus

CODE	NAME	Function
01	Write Coil Status	Use to write output and input status
03	Read Holding registers	Use to read PV for 8-channels
04	Read input registers	Use to read programmable registers
05	Force Single Coil	Use to set or reset the coil
06	Preset Single register	Use to write programmable register

Table 15. Exception responses for Modbus

Code	Name	Meaning
01	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the slave. If a Poll Program Complete command was issued, this code indicates that no program function preceded it.
02	ILLEGAL DATA ADDRESS	The data address received in the query is not an allowable address for the slave
03	ILLEGAL DATA VALUE	A value contained in the query data field is not an allowable value for the slave
06	Slave Device Busy	When Master device write some parameters to Slave device If slave device busy it will send 06 code to indicate slave device is busy.

Table 16. Modbus values for OPEN, OVER, UNDER and SKIP Conditions

SR. NO.	Parameter	Value
1	Open sensor	32767
2	Over reading	32766
3	Under reading	32765
4	Skip Channel	32764

Table 17. Modbus Parameter Details for Process Value

SR. NO.	Parameter	Absolute Address	Parameter Type	Min Value	Max Value	Access Type	NOTE
1	PV Channel - 1	30001	INT	-	-	R	
2	PV Channel - 2	30002	INT	-	-	R	
3	PV Channel - 3	30003	INT	-	-	R	
4	PV Channel - 4	30004	INT	-	-	R	
5	PV Channel - 5	30005	INT	-	-	R	
6	PV Channel - 6	30006	INT	-	-	R	
7	PV Channel - 7	30007	INT	-	-	R	
8	PV Channel - 8	30008	INT	-	-	R	
9	Ambient	30009	INT	-	-	R	

Table 18. Modbus Parameter Details for Holding Register

SR. NO.	Parameter	Absolute Address	Parameter Type	Min Value	Max Value	Access Type	NOTE
1	SP.1 CH - 1	40001	INT	Refer Table 20	Refer Table 20	R/W	
2	SP.1 CH - 2	40002	INT	Refer Table 20	Refer Table 20	R/W	
3	SP.1 CH - 3	40003	INT	Refer Table 20	Refer Table 20	R/W	
4	SP.1 CH - 4	40004	INT	Refer Table 20	Refer Table 20	R/W	
5	SP.1 CH - 5	40005	INT	Refer Table 20	Refer Table 20	R/W	
6	SP.1 CH - 6	40006	INT	Refer Table 20	Refer Table 20	R/W	
7	SP.1 CH - 7	40007	INT	Refer Table 20	Refer Table 20	R/W	
8	SP.1 CH - 8	40008	INT	Refer Table 20	Refer Table 20	R/W	
9	SP.2 CH- 1	40009	INT	Refer Table 20	Refer Table 20	R/W	
10	SP.2 CH- 2	40010	INT	Refer Table 20	Refer Table 20	R/W	
11	SP.2 CH- 3	40011	INT	Refer Table 20	Refer Table 20	R/W	
12	SP.2 CH- 4	40012	INT	Refer Table 20	Refer Table 20	R/W	
13	SP.2 CH- 5	40013	INT	Refer Table 20	Refer Table 20	R/W	
14	SP.2 CH- 6	40014	INT	Refer Table 20	Refer Table 20	R/W	
15	SP.2 CH- 7	40015	INT	Refer Table 20	Refer Table 20	R/W	
16	SP.2 CH- 8	40016	INT	Refer Table 20	Refer Table 20	R/W	
17	HYS CH - 1	40017	INT	1	250	R/W	
18	HYS CH - 2	40018	INT	1	250	R/W	
19	HYS CH - 3	40019	INT	1	250	R/W	
20	HYS CH - 4	40020	INT	1	250	R/W	
21	HYS CH - 5	40021	INT	1	250	R/W	
22	HYS CH - 6	40022	INT	1	250	R/W	
23	HYS CH - 7	40023	INT	1	250	R/W	
24	HYS CH - 8	40024	INT	1	250	R/W	
25	INPUT TYPE CH - 1	40025	INT	Refer Table 20	Refer Table 20	R/W	
26	INPUT TYPE CH - 2	40026	INT	Refer Table 20	Refer Table 20	R/W	
27	INPUT TYPE CH - 3	40027	INT	Refer Table 20	Refer Table 20	R/W	
28	INPUT TYPE CH - 4	40028	INT	Refer Table 20	Refer Table 20	R/W	
29	INPUT TYPE CH - 5	40029	INT	Refer Table 20	Refer Table 20	R/W	
30	INPUT TYPE CH - 6	40030	INT	Refer Table 20	Refer Table 20	R/W	
31	INPUT TYPE CH - 7	40031	INT	Refer Table 20	Refer Table 20	R/W	
32	INPUT TYPE CH - 8	40032	INT	Refer Table 20	Refer Table 20	R/W	
33	SPAN CH - 1	40033	INT	Refer Table 20	Refer Table 20	R/W	
34	SPAN CH - 2	40034	INT	Refer Table 20	Refer Table 20	R/W	
35	SPAN CH - 3	40035	INT	Refer Table 20	Refer Table 20	R/W	
36	SPAN CH - 4	40036	INT	Refer Table 20	Refer Table 20	R/W	
37	SPAN CH - 5	40037	INT	Refer Table 20	Refer Table 20	R/W	
38	SPAN CH - 6	40038	INT	Refer Table 20	Refer Table 20	R/W	
SR.	Parameter	Absolute	Parameter	Min Value	Max Value	Access	NOTE

NO.		Address	Type			Type	
39	SPAN CH - 7	40039	INT	Refer Table 20	Refer Table 20	R/W	
40	SPAN CH - 8	40040	INT	Refer Table 20	Refer Table 20	R/W	
41	ZERO CH - 1	40041	INT	Refer Table 20	Refer Table 20	R/W	
42	ZERO CH - 2	40042	INT	Refer Table 20	Refer Table 20	R/W	
43	ZERO CH - 3	40043	INT	Refer Table 20	Refer Table 20	R/W	
44	ZERO CH - 4	40044	INT	Refer Table 20	Refer Table 20	R/W	
45	ZERO CH - 5	40045	INT	Refer Table 20	Refer Table 20	R/W	
46	ZERO CH - 6	40046	INT	Refer Table 20	Refer Table 20	R/W	
47	ZERO CH - 7	40047	INT	Refer Table 20	Refer Table 20	R/W	
48	ZERO CH - 8	40048	INT	Refer Table 20	Refer Table 20	R/W	
49	Decimal Point CH - 1	40049	INT	0	3	R/W	
50	Decimal Point CH - 2	40050	INT	0	3	R/W	
51	Decimal Point CH - 3	40051	INT	0	3	R/W	
52	Decimal Point CH - 4	40052	INT	0	3	R/W	
53	Decimal Point CH - 5	40053	INT	0	3	R/W	
54	Decimal Point CH - 6	40054	INT	0	3	R/W	
55	Decimal Point CH - 7	40055	INT	0	3	R/W	
56	Decimal Point CH - 8	40056	INT	0	3	R/W	
57	RLY-Logic.1	40057	INT	0	1	R/W	
58	RLY-Logic.2	40058	INT	0	1	R/W	
59	RLY-Logic.3	40059	INT	0	1	R/W	
60	RLY-Logic.4	40060	INT	0	1	R/W	
61	RLY-Function.1	40061	INT	0	1	R/W	
62	RLY-Function.2	40062	INT	0	1	R/W	
63	RLY-Function.3	40063	INT	0	1	R/W	
64	RLY-Function.4	40064	INT	0	1	R/W	
65	RLY-Delay.1	40065	INT	1	99	R/W	
66	RLY-Delay.2	40066	INT	1	99	R/W	
67	RLY-Delay.3	40067	INT	1	99	R/W	
68	RLY-Delay.4	40068	INT	1	99	R/W	
69	RLY-OpenSensor.1	40069	INT	0	1	R/W	
70	RLY-OpenSensor.2	40070	INT	0	1	R/W	
71	RLY-OpenSensor.3	40071	INT	0	1	R/W	
72	RLY-OpenSensor.4	40072	INT	0	1	R/W	
73	RLY-Map CH - 1	40073	INT	0	4	R/W	
74	RLY-Map CH - 2	40074	INT	0	4	R/W	
75	RLY-Map CH - 3	40075	INT	0	2/4	R/W	
76	RLY-Map CH - 4	40076	INT	0	2/4	R/W	
77	RLY-Map CH - 5	40077	INT	0	2/4	R/W	
78	RLY-Map CH - 6	40078	INT	0	2/4	R/W	
79	RLY-Map CH - 7	40079	INT	0	2/4	R/W	
80	RLY-Map CH - 8	40080	INT	0	2/4	R/W	
81	RLY-Type.1	40081	INT	0	2/4	R/W	
82	RLY-Type.2	40082	INT	0	2/4	R/W	
83	RLY-Type.3	40083	INT	0	2/4	R/W	
84	RLY-Type.4	40084	INT	0	2/4	R/W	
85	SKIP-Channel CH - 1	40085	INT	0	1	R/W	
86	SKIP-Channel CH - 2	40086	INT	0	1	R/W	
87	SKIP-Channel CH - 3	40087	INT	0	1	R/W	
88	SKIP-Channel CH - 4	40088	INT	0	1	R/W	
89	SKIP-Channel CH - 5	40089	INT	0	1	R/W	
90	SKIP-Channel CH - 6	40090	INT	0	1	R/W	
91	SKIP-Channel CH - 7	40091	INT	0	1	R/W	
92	SKIP-Channel CH - 8	40092	INT	0	1	R/W	
93	RLY Latch	40093	INT	0	1	R/W	
94	RLY Group	40094	INT	0	1	R/W	
SR. NO.	Parameter	Absolute Address	Parameter Type	Min Value	Max Value	Access Type	NOTE

95	Scan Rate	40095	INT	1	250	R/W	
96	Auto CJC	40096	INT	0	1	R/W	
97	Fix CJC	40097	INT	0	600	R/W	
98	Machine ID	40098	INT	1	247	R/W	
99	Baud Rate	40099	INT	0	1	R/W	
100	Parity/Stop Bit	40100	INT	0	3	R/W	
101	Timeout	40101	INT	10	60	R/W	
102	PV Scale Retransmission	40102	INT	0	1	R/W	
103	Retransmission Type	40103	INT	0	4	R/W	
104	Retransmission Direction	40104	INT	0	1	R/W	
105	Retransmission CH - 1	40105	INT	0	1	R/W	
106	Retransmission CH - 2	40106	INT	0	1	R/W	
107	Retransmission CH - 3	40107	INT	0	1	R/W	
108	Retransmission CH - 4	40108	INT	0	1	R/W	
109	Retransmission CH - 5	40109	INT	0	1	R/W	
110	Retransmission CH - 6	40110	INT	0	1	R/W	
111	Retransmission CH - 7	40111	INT	0	1	R/W	
112	Retransmission CH - 8	40112	INT	0	1	R/W	
113	Retransmission Value	40113		0	1	R/W	
114	Retransmission Channel selection	40114	INT	1	8	R/W	
115	Password	40115	INT	0	9999	R/W	
116	Future use						
117	Future use						
118	Future use						

SR. NO.	Parameter	Absolute Address	Parameter Type	Min Value	Max Value	Access Type	NOTE
1	Calibration Password	49001	INT	0	65000	W	
2	Ambient Calibration	49002	INT	-	-	W	
3	Zero Calibration Channel-1	49003	INT	-	-	W	
4	Zero Calibration Channel-2	49004	INT	-	-	W	
5	Zero Calibration Channel-3	49005	INT	-	-	W	
6	Zero Calibration Channel-4	49006	INT	-	-	W	
7	Zero Calibration Channel-5	49007	INT	-	-	W	
8	Zero Calibration Channel-6	49008	INT	-	-	W	
9	Zero Calibration Channel-7	49009	INT	-	-	W	
10	Zero Calibration Channel-8	49010	INT	-	-	W	
11	Span Calibration Channel-1	49011	INT	-	-	W	
12	Span Calibration Channel-2	49012	INT	-	-	W	
13	Span Calibration Channel-3	49013	INT	-	-	W	
14	Span Calibration Channel-4	49014	INT	-	-	W	
15	Span Calibration Channel-5	49015	INT	-	-	W	
16	Span Calibration Channel-6	49016	INT	-	-	W	
17	Span Calibration Channel-7	49017	INT	-	-	W	
18	Span Calibration Channel-8	49018	INT	-	-	W	

Table 19. Modbus Parameter Details for Read Output Status(Read Coil) Register

SR. NO.	Parameter	Absolute Address	Parameter Type	Access Type
1	Alarm.1 Channel-1	1	BIT	R
2	Alarm.1 Channel-2	2	BIT	R
3	Alarm.1 Channel-3	3	BIT	R
4	Alarm.1 Channel-4	4	BIT	R
5	Alarm.1 Channel-5	5	BIT	R
6	Alarm.1 Channel-6	6	BIT	R
7	Alarm.1 Channel-7	7	BIT	R
8	Alarm.1 Channel-8	8	BIT	R
9	Alarm.2 Channel-1	9	BIT	R
10	Alarm.2 Channel-2	10	BIT	R
11	Alarm.2 Channel-3	11	BIT	R
12	Alarm.2 Channel-4	12	BIT	R
13	Alarm.2 Channel-5	13	BIT	R
14	Alarm.2 Channel-6	14	BIT	R
15	Alarm.2 Channel-7	15	BIT	R
16	Alarm.2 Channel-8	16	BIT	R
17	RELAY STATUS-1	17	BIT	R
18	RELAY STATUS-2	18	BIT	R
19	RELAY STATUS-3	19	BIT	R
20	RELAY STATUS-4	20	BIT	R
21	Auto/Manual Mode	21	BIT	R/W
22	Acknowledge For Relay	22	BIT	W
23	Unused	-	-	-
24	Unused	-	-	-

NOTE: For Auto/Manual Mode, to set Manual mode bit value = 1 and to set Auto mode bit value = 0.
 For Acknowledgement function, to give acknowledge for relay bit value = 1.

Table 20. Input Type Selection Table

Input Type	I/P no	Type Display	Zero	Span	Resolution
------------	--------	--------------	------	------	------------

E	1	E tc	-200	1000	0.1°C
J	2	J tc	-200	1200	0.1°C
K	3	K tc	-200	1370	0.1°C
T	4	T tc	-200	400	0.1°C
B	5	B tc	450	1800	1°C
R	6	R tc	0	1750	1°C
S	7	S tc	0	1750	1°C
N	8	n tc	0	1300	0.1°C
RTD	9	RTD	-199.9	850.0	0.1°C
-10 to 20mv	10	-10.20	-1999	9999	1 Count
0-75mV	11	0-75	-1999	9999	
0-100mV	12	0-100	-1999	9999	
0 to 2V	13	0-2V	-1999	9999	
0.4 to 2V	14	0.4-2V	-1999	9999	
4 TO 20mAmp	15	4-20	-1999	9999	
0 to 20 mAmp	16	0-20	-1999	9999	
0-5V	17	0-5V	-1999	9999	
1-5V	18	1-5V	-1999	9999	
0-10V	19	0-10V	-1999	9999	

Table 21. Relay Logic Selection

Modbus Index	Parameter Value
0	Normal
1	Fail Safe

Table 22. Relay Function Selection

Modbus Index	Parameter Value
0	Alarm
1	Trip

Table 23. Relay Open Sensor Selection

Modbus Index	Parameter Value
0	Down
1	Up

Table 24. Relay Group-4 Selections

Modbus Index	Parameter Value
0	None
1	G-1(RELAY – 1)
2	G-2(RELAY – 2)
3	G-3(RELAY – 3)
4	G-4(RELAY – 4)

Table 25. Relay Group-2 Selections

Modbus Index	Parameter Value
0	None
1	G - 1(RELAY 1 & 3)
2	G – 2(RELAY 2 & 4)

Table 26. Relay Group-4 Type Selections

Modbus Index	Parameter Value
0	Low ON
1	High ON

Table 27. Relay Group-2 Type Selections

Modbus Index	Parameter Value
--------------	-----------------

0	High/Very High
1	Low/Very Low
2	High/LOW

Table 29. Relay per Group Selection

Modbus Index	Parameter Value
0	Relay Per Group – 4
1	Relay Per Group – 2

Table 31. Parity/Stop Bit Selection

Modbus Index	Parameter Value
0	Parity-None/Stop Bit - 1
1	Parity-None/Stop Bit - 2
2	Parity Odd/Stop Bit – 1
3	Parity Even/Stop Bit – 1

Table 33. Retransmission Type Selection

Modbus Index	Parameter Value
0	0 – 20mAmp
1	4 – 20mAmp
2	0 – 5V
3	1 – 5V
4	0 – 10V

Table 35. Retransmission Value Selection

Modbus Index	Parameter Value
0	Minimum
1	Maximum

Table 28. Relay Latch Selection

Modbus Index	Parameter Value
0	OFF
1	ON

Table 30. Com Port Baud Rate Selection

Modbus Index	Parameter Value
0	9600bps
1	19.2kpbs

Table 32. Retransmission Open Sensor Selection

Modbus Index	Parameter Value
0	Down
1	Up

Table 34. Retransmission Direction Selection

Modbus Index	Parameter Value
0	Reverse
1	Direct

10. MISCELLANEOUS

Table 36. PV Input Status Display During Burnout Condition

Input type	Display Message
TC-E	OPEN(oPEn)
TC-J	OPEN
TC-K	OPEN
TC-T	OPEN
TC-N	OPEN
TC-B	OPEN
TC-R	OPEN
TC-S	OPEN
PT 100(RTD)	OPEN
0-10V DC	OPEN
0 to 5V DC	OPEN
1 to 5V DC	OPEN
0 to 2V DC	OPEN
0.4 to 2V DC	OPEN
0 to 20mA	PV LOW
4 to 20mA	PV LOW
-10 to 20mV DC	OPEN
0-100mV DC	OPEN
0-75mV DC	OPEN

Note: If set PV_low/PV_high for input type is less than maximum value of zero and span for then process value will display readings above 5% of display range, then after it will show **oVER/UnDR** (OVER/UNDER) message until value crosses maximum value of Sensor range. Process value greater than maximum value of zero/span then display will show **oPEn** (OPEN) message. Retransmission o/p will follow 5% of display range and then it will give fixed o/p depending up on OPEN sensor selection. In case of linear inputs scaling is applied then during OPEN sensor condition it may not show **oPEn** (OPEN) message instead it will show either **oVER/UnDR** (OVER/UNDER).

Table 37. Retramission Output Table For Open /Over /Under Condition

RETRASMISSION	VARIABLE	SCALE	ACTION	OPEN	OVER	UNDER	ERROR
4-20mamp	PV	UP	DIR	20.8	20.8	3.2	-
	PV	DOWN	REV	20.8	3.2	20.8	-
	PV	UP	REV	3.2	3.2	20.8	-
	PV	DOWN	DIR	3.2	20.8	3.2	-


NOTE: - 1) For Retransmission output type 0-20mamp, 0-10v, 1-5v and 0-5v also applicable according to above table.

2) Also, 0-20mamp, 0-10v and 0-5v minimum output value will be 0mamp and 0v respectively.

11. TROUBLESHOOTING

If the operating display does not appear after turning on the Scanner / DAQ's power, follow the measures in the procedure below.

If a problem appears complicated, contact our sales representative.



Sonepar India Pvt. Ltd.

B/30, GIDC Electronics Estate,
Sector-25, Gandhinagar-382016, Gujarat, India

Phone: +91 79 23287275-77

Email: support.masibus@soneparindia.com

Web: www.masibus.com