


**Configuration Mode-2**

Issue No.:00



**Calibration Mode and Security Mode Flow diagram**

For operation manual please visit [www.masibus.com](http://www.masibus.com)  
Specifications are subject to change without notice due to continuous improvements.

**Masibus Automation And Instrumentation Pvt. Ltd.**  
B-30, GIDC Electronics Estate, Sector-25, Gandhinagar-382044, Gujarat, India.  
Tel: +91 79 23287275-79 Fax: +91 79 23287281  
Web: [www.masibus.com](http://www.masibus.com) Email: support@masibus.com