







Calibration



Factory Reset



Procedure for changing/setting different values to different channels in all levels is shown in the level 1 Hysteresis setting."See Hys setting"

For operation manual please visit www.masibus.com
 Specifications are subject to change without notice due to continuous improvements.
Masibus Automation And Instrumentation Pvt. Ltd.
 B-30, GIDC Electronics Estate, Sector-25, Gandhinagar-382044, Gujarat, India.
 Tel: +91 79 23287275-79 Fax: +91 79 23287281
 Web: www.masibus.com Email: support@masibus.com